KONAN[®]

Download CAD drawings and PDF catalog data from the following website

URL=https://www.konan-em.com/

3/4/5 Port • For pnematic control

Explosion-proof / Compact explosion-proof For hydrogen / Intrinsic safety solenoid valves

Explosion-proof and drip-proof solenoid valve lineup



Variety of explosion-proof / drip-proof

Application Proof types For general pnematic control **Explosion-proof** d2G4 construction standard for electric equipment Flame-proof enclosure Listed in this catalog. construction d3aG4 (Explosion-proof for hydrogen) **Technical standards** conforming to the Exd II BT4 international standards

Drip-proof


NEMA4 drip-proof: Conforms to JIS C 0920 (protection class:5/jet-proof) and IEC 144 (protection class:IP55)

NEMA4,7 explosion-proof, drip-proof: Conforms to JIS C 0920 (protection class:5/jet-proof) and IEC 144 (protection class:IP65)

Technical standards conforming to the international standards

i2G4

Exia II BT5



Intrinsic safety construction

For pnematic control

3/4/5 Port Explosion-proof 4/5 Port For hydrogen

5 Port Compact explosion-proof
5 Port Intrinsic safety

	Verifying nation			
Feature	Port	External wire connection system	For For For Europe Korea China Taiwan	Page
Marina Makabad	3 Port	Conduit tube system Pressure-resistant packing system		Page A-7
Magnet-latched (Double-acting) For general use	4 Port	Conduit tube system Pressure-resistant packing system		Page A-11
(Single-acting)	5 Port	Conduit tube system Pressure-resistant packing system		Page A-17
Compact explosion-proof	5 Port	Conduit tube system Pressure-resistant packing system		Page B-3
For general use	4 Port 5 Port	Conduit tube system Pressure-resistant packing system		Page C-3
For general use	4 Port	Conduit tube system Pressure-resistant packing system		Page A-11
(single acting)	5 Port	Conduit tube system Pressure-resistant packing system		Page A-17
Compact explosion-proof	5 Port	Conduit tube system Pressure-resistant packing system	• • •	Page B-3
For general use	5 Port	<u>–</u> –		Page D - 9
Magnet-latched (Double-acting) For general use (Single-acting)	3 Port 4 Port 5 Port	Pressure-resistant packing system		Page A-7 Page A-11 Page A-17



For solenoid valves for various fluid, refer to Cat.No.7110E "MAGFLOW series".

List of representative types of overseas authentication, explosion-proof solenoid valves

					External wire connection system	Verifying nation	Model type			
					Conduit tube system	Januari Parametra	MVS80/MVS81			
			Pressure-resistant packing system	Japan	MVD80/MVD81					
				Conduit tube system	Europe					
				4-Port	Pressure-resistant packing system	-				
					Conduit tube system	Korea	MVS80/MVS81			
					Pressure-resistant packing system		MVD8			
					Conduit tube system	China				
					Conduit tube system	Taiwan				
					Wire connection system	Verifying nation	Model type			
					Conduit tube system	verilying nation	Model type			
					Pressure-resistant packing system	Japan				
			Gasket		Conduit tube system	Europe				
			connection type		Pressure-resistant packing system	Lurope	1 1 1 2 2 5 1 1 1 1 D 2 5			
	ם		type		Conduit tube system	Korea	MVS2F/MVD2F MVPCF/MVPOF/MVPEF			
	truction				Pressure-resistant packing system					
	O D				Pressure-resistant packing system	China				
_	tr			5-Port	Pressure-resistant packing system	Taiwan				
r.	enclosure control						Conduit tube system	Tarvari		
ם ד				Pressure-resistant packing system	Japan					
				Pressure-resistant packing system	Europe					
O				Conduit tube system		MVS2F/MVD2F				
				Pressure-resistant packing system	Korea	MVPCF/MVPOF/MVPEF				
Ε				Conduit tube system						
ne				Pressure-resistant packing system	China					
σ	□				Pressure-resistant packing system	Taiwan				
For	r o o				Wire connection system	Varifying nation	Model time			
"	- D				Wire connection system Conduit tube system	Verifying nation	Model type			
	E E							Pressure-resistant packing system	Japan	453S 453D
	a				Pressure-resistant packing system	Europe				
	Fla		Direct piping	5-Port	Conduit tube system	Lurope				
			type	0.1.011	Pressure-resistant packing system	Korea				
					Conduit tube system		453S			
					Pressure-resistant packing system	China				
					Pressure-resistant packing system	Taiwan				
			Compact		Wire connection system	Verifying nation	Model type			
			explosion-proof		Conduit tube system	Japan				
			explosion-proof NAMUR		Pressure-resistant packing system	Japan	4N4S 4N4D			
			explosion-proof		Pressure-resistant packing system Conduit tube system	Japan Korea	4N4S 4N4D			
			explosion-proof NAMUR standard	5-Port	Pressure-resistant packing system Conduit tube system Pressure-resistant packing system					
			explosion-proof NAMUR standard compliant type Compact	5-Port	Pressure-resistant packing system Conduit tube system Pressure-resistant packing system Conduit tube system					
			explosion-proof NAMUR standard compliant type Compact explosion-proof	5-Port	Pressure-resistant packing system Conduit tube system Pressure-resistant packing system Conduit tube system Pressure-resistant packing system	Korea	4N4D 454S			
			explosion-proof NAMUR standard compliant type Compact	5-Port	Pressure-resistant packing system Conduit tube system Pressure-resistant packing system Conduit tube system	Korea	4N4Ď			

Housing	Body size	Port size	Cable size	Rated voltage	Verifying nation	
3E						
2E						
2Y						
3E	- 02					– H
2E	- 02 - 03				_п	
3E					- C	
2E					- 0	
2Y					- W	

Body size
- 03
- 08

	Housing
	1E
	2E
	2Y
	1E
	2E
	1E
	2E
 -E	2Y
-	1E
	2E
	2Y
	1E
	2E
	1E
	2E
	2Y

Port size	Cable size	Rated voltage	Verifying nation
			- H - C - W - H - C - W

Body size	Port size			Housing							
	20 40										1E
20 40		K		2E							
				2Y							
			- E	1E							
				2E							
				1E							
				2E							
				2Y							

Cable size	Rated voltage	Verifying nation
		ш
		— п
		- C
-00		C
		- W

Body size	Port size	
10		К
10 20		

Proof	
- P	
- H	
Е	
Н	

Cable size	Rated voltage
01	
01	
	_ H□
E01	_ H □
-E□□	
E01	
- E □□	

Explosion-proof Solenoid Valves and Valve Systems General Handling Instructions and Precautions

Please read the following general handling instructions and precautions carefully before ordering solenoid

Safety Precautions

References:

Pneumatic fluid power -general rules relating to systems



Following information is based on a risk assessment for Konan products. Each section provides information essential for safe operation of the products and prevention of risk and damage that may affect operators. Please read carefully.

1. Selection of solenoid valves

Solenoid valves are used to activate actuators by switching air flow in a pneumatic system with electrical signals.

In order to ensure safe system operation it is significant to select appropriate valve type. Therefore the entire pneumatic system designer should determine the solenoid valve taking into consideration the required operation, performance, and countermeasure to system failure. Electric components need to have explosion-proof construction respectively depending on the purpose of use, type of explosive gas and dangerous place where the components are used. As electric components having explosion-proof construction show where those components can be used by symbols, check the symbols to select a suitable component.

2. Solenoid valve installation

As pneumatic components are operated with compressed air, sudden blowout, unintended operation by residual air inside actuators (bursting out of a cylinder etc.), and other risks should be taken into account. A sufficiently trained person should be responsible for installation and maintenance of a solenoid valve.

(Konan provides training for operation and maintenance of pneumatic components. Feel free to contact our sales personnel for details.)

This series of solenoid valves is explosion-proof type.

For actual handling of the valves, personnel with sufficient knowledge about explosion-proof wiring should be responsible.

3. Maintenance of solenoid valves

Make sure before maintenance of solenoid valves that the pneumatic system is in a safe position or the system is mechanically fixed.

Compressed air remains as energy even after shut off of air supply. Close the air supply line and exhaust air inside the pneumatic circuit at the same time. Carefully read the details in "7. Maintenance" described

4. Solenoid valve installation site

For use of solenoid valves under following conditions sufficient safety measure should be taken. Consult us for details.

- 1) Operating conditions are not within the specified range.
- 2) Significant risks for users, properties, or environment are anticipated. Eg: Use for nuclear power plants, vehicles, medical components, etc.

Users Instructions



Caution 1.Transport of solenoid valves

- 1) A solenoid valve is supplied in a package. Do not treat the package roughly to prevent valve deformation and other damage that may result in valve operational failure.
- 2) Plastic plugs are attached to the valve connection ports to prevent dusts and rusts from entering the valve during transport or storage before installation. Do not remove the plugs until immediatel before piping.



Caution 2.Storage

1) Installation site

Transport a valve to the specified site just before installation. If the valve is to be stored at the installation site, keep it packed and protect from wind, rain, and dusts.

2) Storage

If a valve is to be stored for more than 1 year, keep it packed. Long-term storage may result in sticking of packings. In such case conduct pre-conditioning operation of the valve before regular use. After a long period of storage, aging, constriction, or deformation of packings would be a concern. Consult us for use of the valves after long period of storage.



Caution 3.Surrounding environment

Solenoid valve is a complex component. Exposure of the valve to excessive shock or vibration may cause operational failure, loosening of clamps, or early wearing of spool packings.

Make sure at installation of the valve that the valve is not in line with the direction susceptible to vibration/shock.

2) Surrounding environment

Environment surrounding a valve should be considered carefully.

Avoid places where the valve is exposed to rain and wind, salt air, corrosive gas, chemical fluids, seawater, steam, etc.

3) Ambient temperature

Sufficient care should be taken for ambient temperature as well as fluid temperature. Even if a valve is installed in a cool place, when heated air inside a cylinder under high temperature environment is exhausted through the valve, it may cause deterioration of packings or valve operational failure due to thermal expansion of the internal components.

4) Breathing hole

The main valve and pilot solenoid valve are equipped with a breathing hole required for operation. As it is possible that water, foreign materials, etc. enter through the breathing hole, take measures by adjusting the attachment position, adding a cover, etc.



Caution 4.Piping

1) Disposal of drains

For use of a valve at lower limit of working pressure, care should be taken for lubrication, disposal of drains, and supply air volume. (Inlet port should be as large as possible. If possible install an air tank in front of the valve.)

2) Compressed air

Air supplied to a valve should be filtrated by air filter with nominal filtration range of no more than 40µm to avoid excessive drain or oil. Contaminated air may cause deterioration of packings and other components, which leads to extremely short life of the valve or early operational failure. In the case of intrinsic safety solenoid valves, use air filters less than 5µm.

In the case of using air whose dryness is high (dew point is -40°C or less), it is possible that shortage of lubricant occurs at an early stage, which shortens the service life. Consult with our sales

3) Piping

Do not remove plastic plugs attached to the valve connection ports until immediately before piping in order to prevent dusts and rusts from entering the valve during transport or storage before installation. For steel tube piping make sure to use galvanized pipe.

4) Pipe narrowing

Do not narrow part of valve inlet ports. Especially when vinyl or other resinous tube is used for piping and air flow path at the tube joint is extremely narrow, air flow rate decreases and thus operational failure may occur. Sufficient care should also be taken when using copper tube joint and rubber hose joint.

5) Pipe length

If cylinder speed is adjusted by reducing air exhausted from a 5-port solenoid valve, confirm the limit of the air reduction. If pipe volume between the solenoid valve and the cylinder is large, favorable speed control cannot be achieved. Make sure that the pipe volume / cylinder volume is not more than 0.1.

6) Pipe cleaning

After piping is completed, clean the pipe by air flushing. Use clean air for fluid, as dusts and drain in the fluid cause significant harm to the valve function and shorten the valve life.

7) Piping connection

Make sure to perform correct piping connection.

As pneumatic solenoid valves make significant noise at air exhaustion, use silencer or other means to absorb noise.

Konan provides silencers that meet various types of solenoid valves as well as silencers incorporating throttle valve.

8) Pipe screwing

When a pipe or a nipple is screwed to a solenoid valve, up to 4 or 5 threads should be screwed for 6A to 25A (Rc1/8 - 1) port size. Any forceful screwing beyond this may result in cracking of the valve body or leakage/malfunction. Care should also be taken for contamination with fragments of sealing materials. In the case of direct piping type, make sure not screwing up mounting screw too tight at valve installation.

9) Piping of manifold type solenoid valves

Manifold type solenoid valves should be operated by sequence control of individual valves in principle. If 2 or more valves are operated simultaneously, inlet supply pressure drops or supply pressure volume to loading components decreases. Up to 3 units can be operated simultaneously. Inlet port and exhaust port are at both end of manifold base to enable piping from either direction. Seal unnecessary ports with plugs. For accomplishment of accurate operation piping at both end of manifold base (2 sites) is recommended



Caution 5.Lubrication

Explosion-proof pneumatic solenoid valves can be used without lubrication. If lubricating oil is to be used, care should be taken for the oil quality. Packings incorporated in the valves can contribute to stable valve operation only with quality mineral oil. Inappropriate lubricating oil deteriorates sealing quality. Especially use of spindle oil often causes expansion of packings. Also make sure to select oil that does not emulsify with drain. JIS K 2213 (ISO VG32 or VG46) type turbine oil is recommended for lubricating oil.

After lubrication do not use the valve without lubrication or the valve life may become extremely short.



Caution 6. Wiring

1) Explosion-proof wiring

For lead-in of conductors into the terminal box, follow the "Recommended Practices for Explosion-protected Electrical Installation in General Industries" (issued by the National Institute of Occupational Safety and □Health.)

i) Conduit tube type

Use thick steel conduit and screw 5 or more threads at the screw joint. As the explosion-proof performance depends on the screwing precision, care should be taken for conduit installation. Elbow, flexible, or union joints to be used should also be explosion-proof type.Konan conduit type screw is G1/2.

ii) Pressure-resistant packing type

Use pressure-resistant packing type connector when performing cable wiring. (Approved pressure-resistant packing type connector should be used. Use the connector attached to the solenoid valve.)

Before wiring, make sure that cables conform to the cable size described on the products.

Applied voltage

Do not apply voltage with the terminal box opened. Check the valve nameplate and apply specified rated voltage. Use of the valve with inappropriate voltage may result in coil damage or valve operational failure. Use the valve after checking if voltage fluctuation is within allowable range. If the valve is used with voltage not within the specified range, solenoid burnout and other failure may occur. The allowable voltage range means that instant valve operation can be performed without problem within the range, not that the valve can be continuously operated within the range.



Warning 7.Maintenance

Use conditions of solenoid valves differ depending on users.

The complying method varies depending on users, for example, whether preventive maintenance or breakdown maintenance is employed. The maintenance method is different depending on use conditions and importance of facilities. From the above situation, we propose recommended replacement intervals from the standpoints of preventive maintenance.

1) Maintenance should be performed in accordance with the maintenance manual.

As a pilot solenoid valve is an explosion-proof component, do not disassemble it. Disassembly may impair the explosion-proof performance, resulting in accidents. When replacing a pilot solenoid valve, use a finished part.

If it is necessary to disassemble pilot solenoid valves formaintenance, etc., consult with our sales personnel.

- 2) Follow the below steps when uninstalling a solenoid valve.
 - i) Shut off supply pressure.
 - ii) Exhaust residual pressure inside pneumatic circuit. Compressed air remains as energy even after shut off of air supply. Exhaust pressure inside the pneumatic circuit using residual pressure exhaust valve, relief function of a regulator, or drain cock of an air filter.
 - iii) Shut down power source.

Not only disconnect the solenoid valve side terminal but also turn off the power source.

iv) Uninstall the valve.

3) Operation frequency

Explosion-proof pneumatic solenoid valves are soft seal spool type solenoid valve series using squeeze packings. According to the JIS standard, minimal operation frequency of this type of valve is specified as once in 30 days.

For safety maintenance should therefore be performed once in 30 days.

4) Push button

If a push button of a solenoid valve is pushed, the valve coil is energized. Care should be taken so that a third party does not push the button without discretion. A cap with which a push button part is covered protects a push button from being operated by mistake and water from intruding into the inside of housing. Do not remove the cap except when it is necessary to operate the push button.


Explosion-proof Solenoid Valves and Valve Systems General Handling Instructions and Precautions

Compact explosion proof solenoid valve 4N4 · 454 series

Electrical connection


[Structural standard]

The cover of the terminal box is built in a locking system to be opened or closed by a special tool. When opening or closing, use the special tool furnished to the product, and fit the end of the tool tightly to the groove of the cover, and turn in the opening or closing direction as shown in the drawing.



[Ex. explosion-proof]

The cover of the terminal box can be opened or closed by spanner or the like.furnished to the product, and fit the end of the tool tightly to the groove of the cover, and turn in the opening or closing direction as shown in the drawing.



\triangle

Warning Wiring

- Before opening or closing the terminal box or when detaching or attaching the electrical terminals, be sure to turn off the power source in advance.
- When connecting wires outdoors or in a place where water may intrude, take protective measures properly to prevent rainwater or the like intruding into the terminal box.



Explosion-proof and drip-proof solenoid valve lineup Vol. 1

For pnematic control 3/4/5 Port

Explosion-proof solenoid valve



vol.1 Explosion-proof solenoid valves

d2G4 Exd II BT4

Explosion-proof construction standard for electric equipment

Technical standards conforming to the international standards

Ultra-Compact Solenoid Valves whitch Utilize Advanced Watertight and Explosion-Proof Technology



• For the prevention of mis-operation, a standardized cover cap is provided on the terminal unit.




■ The enlarged wiring space of the terminal block permits 270°C rotation by single bolt operation in the same way as for solenoid housing, thus significantly facilitating the explosion-proof electrical work to be carried out with extreme care.



- The solenoid housing may rotated by 360 °C ,thus permitting the cable outlet to be installed optionally in 3-dimensional direction.
- The installation work can be performed readily by the use of the use of a single bolt.



- The use of a magnet-latched solenoid allows two coils to be housed within a single casing, thus reducing the number of cable outlets to one.
- The moving iron core attracted and retained to the fixed iron core (1) by the magnetic field (1) of the permanent magnet is freed from the magnetic field (1) and attracted to the fixed iron core (2) when the coil (2) is energized. The moving iron core is retained by the magnetic field (2) even when the coil is de-energized.
- When the coil (1) is energized, the moving iron is freed by the magnetic field (2) and attracted to the fixed iron core. The moving iron core is retained by the magnetic field (1) even when the coil is de-energized.






 simple,easy-handling,water-proof,pressure-resistant packing type cable gland is provided as a standard component.




- Simple push-button operation permits direct manual control of the moving iron core. The manual operation is practicable irrespective of energization or de-energization.
- To take full advantage of the features of the magnet-lached solenoid,manual locking is effected by the magnetic circuit of permaned magnet.
 - (Vibration resistance and impact resistance of the manually-operated lock are not less than 3G and 7G respectively.)



 An innovative lubrication-free slide selector applied with high-hardness ceramics is incorporated, thus providing a semi-permanet durability and the most suitable application for high/ low frequency operations. The main models of Konan's double acting explosion-proof solenoid valve are applied Konan's newly-developed magnet-latched solenoid. Furthermore, the innovative 4-port solenoid valve is mounted with a slide-type ceramic valve disc excellent in durability.



Model List



2 • 3 Port

3/4/5 Port • For pnematic control Explosion-proof and drip-proof solenoid valves

To meet diversified customer needs, Konan's drip-proof and explosion-proof sorenoid valves are available in a variety of types as shown in the following list. Especially, the double-acting solenoid valve equipped with a newlydevelopped magnet-lached solenoid has been made compact enough in shape to eliminate its conventional image, such as reduction in number of cable outlets to one.

Among the explosion-proof and drip-proof solenoid valves, various kinds of manifold type combined with models given in the following list are also manufactured. For details, consult separately.

> Type of Construction for **Explosion-proof and Drip-proof**



Cautions for use



Flame-proof enclosure construction

> : d2G4 Exd II BT4

Specification A-7 Model Code A-8 A-8 Wire connections Precautions in control A-8 circuit design A-9 External Dimensions · · ·



Conduit tube system

Pressure-resistant

packing system

Drip-proof protection class: IP66

Specification Model Code

Wire connections Precautions in control . . . A-12 circuit design External Dimensions · · · A-13



Drip-proof protection class: IP66 Can be used outdoors

> Specification Model Code Wire connections · · · · A-18 Precautions in control circuit design External Dimensions · · · A-19



Drip-proof

Drip-proof protection class: Equivalent to IP54

Return.	Hold					
Specification		•	•	•	•	A-23
Model Code		•	•	•	•	A-24
Wire connect	tions	•	•	•	•	A-24
Precautions in circuit design	contro	l	•	•	•	A-24
External Dim	ensior	าร	•	•	•	A-25



3-Position Type

Specification Model Code · A-30 Wire connections · · · · A-30 Precautions in control · · · A-31 circuit design

Besides the solenoid valves given in the above list, explosion-proof solenoid valves for use with various kinds of fluid such as air, gas, oil, steam, chemical solutions, etc. are available. For details, refer to No.7110E catalogue.

Cautions for use



Lubrication of the solenoid valve main body is not needed, but when lubrication of other devices is needed, use JISK2213 additive turbine oil ISO VG32 or VG46.




When operating two or more solenoid valves of manifold type simultaneously, note that that the P port (supply) pressure may be lowered, or that the flow rate to the load device may decline. For obtaining a more secure operation, the both-end P and R port piping is recommended.



Operation of manual push button (pilot solenoid valve)


In case of single solenoid



- 1) Remove the aluminum protective cap (screw-in type), and manipulate (push up) the push button.
- 2) Note that that the standard type is not locked.
 - * If lock mechanism is needed, specify when ordering the product.


In case of Magnet-latched type

A) Remove the rubber-made protective cap (red), and manipulate the push button.



- SOL. A side SOL. B side
- SOL. A side —— Push down.
- SOL. B side —— Push up.

<Caution> Solenoid valve type: Only in case of MVD311K-02, MVD312K-02, and MVD313K-02, the solenoid valves SOL. A and SOL.B are as shown below.



- SOL. A side ——Push up.
- SOL. B side ——Push down.

- B) Note that that the solenoid of Magnet-latched type is not provided with locking mechanism.
- % In any case, be sure to put on the protective cap after use of the manual push button.



If leaving it behind without use for 1 year or longer, check it before use.

MVS300K/MVD300K Series

3-Port Solenoid Valves

Explosion-proof, Drip-proof

Poppet valve system, Direct acting type

Direct piping type Rc1/4

Return / Hold



Specifications

			Return	Hold	Return	Hold	
		Drocoure registent					
۵	Explosion-	Pressure-resistant packing	MVS302K - 02	MVD302K - 02	MVS312K - 02	MVD312K - 02	
Туре	proof type	Conduit tube	MVS303K - 02	MVD303K - 02	MVS313K - 02	MVD313K - 02	
	Drip-pro	of type	MVS301K - 02	MVD301K - 02	MVS311K - 02	MVD311K - 02	
Por	rt size (R	c)		1/	/4		
Effe	ective section	onal area (CV value)	1 mm (0.05)	4mm [*]	(0.2)	
Оре	erating pre	essure	0~0	.7MPa	0~0	.1MPa	
Pre	essure resi	stance		1.05	MPa		
Оре	Operating temperature		- 20 ~ 60°C				
Оре	erating fre	quency	1 cycle / s max.				
Оре	Operation (response) time		0.05s max.				
	Rated vo	oltage	Refer to Model Code				
	Voltage f	luctuation tolerance	− 15%~ 10% of rated voltage				
<u>ē</u>	Tempera	ature rise	80 deg max.	65 deg max.	80 deg max.	65 deg max.	
Solenoid	Insulatio	n class	Class H				
Š	Insulatio	n resistance	10MΩ min.				
	Rated co	urrent	Refer to Rated current data on page A-39				
	Explosio	n-proof standard	Flame-proof enclosure construction d2G4				
Ма	SS			Approx	. 1.3kg		

ullet At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.

■ Return • explosion-proof verification approval No.

No. T47926

■ Hold • explosion-proof verification approval No.

No. T34655

Safety Integrity Level

"MVS302K-02-8A" is a product equivalent to "SIL3".

Safety Integrity Level, discrete level (one out of possible four) for specifying the safety integrity requirements of the safety functions to be allocated to the E/E/PE safety-related systems where Safety Integrity Level 4 is the highest level and Safety Integrity Level 1 is the lowest.

Safety Integrity Leve	PFDavg (Average Probability of Failure on Demand)
SIL 4	Less than 10^{-5} more 10^{-4}
SIL 3	Less than 10^{-4} more 10^{-3}
SIL 2	Less than 10 ⁻³ more 10 ⁻²
SIL 1	Less than 10^{-2} more 10^{-1}

Model Code

When ordering, specify the model as follows:



1 Type of flow path

-	Type of valve	JIS symbol	Designation
position	Return	SOL	S
2 po	Hold (Magnet-latched system)	SOLB TITES SOLA	D

 \bullet This valve is commonly used from normally-closed and normally-open positions

4 Applicable cable size (when housing is 1K* or 2K*)

Wire size	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	ϕ 10.5 \sim 11.4	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13

% For size ϕ d, refer to page A-35 from A-38

2 Kind of operating pressure

Operating pressure	Effective sectional area	Designation
0~0.7MPa	1 mm²	0
0~0.1 MPa	4mm [*] (Large flow type)	1

3 Type of housing

Type o	Type of housing (External wire connection system) Designation				
xplosion- roof type	Pressure resistant packing system	2K *			
Explc proof	Conduit tube system	ЗК			
	Drip-proof type 1K*				

^{**} In the case of pressure resistant packing system, drip-proof type please enter the 4 applicable cable size.

In the case of conduit tube system, no need to fill out the 4 applicable cable size.


5 Rated voltage


Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 50/60Hz	AC120
AC125V 50/60Hz	AC125
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V

(Pressure-resistant packing)

[Conduit tube]


MVS302K-02 MVS312K-02 (Return) MVS303K-02 MVS313K-02 (Return)






MVD302K-02 (Hold)


MVD303K-02 (Hold)






[Drip-proof type]

MVS301K-02 MVS311K-02 (Return)



MVD301K-02 MVD311K-02 (Hold)




Precautions in operation circuit design

< Cause of magnet-latched system > (Hold)

If the load L such as relay, lamp or the like is connected in parallel with coil as shown in Fig.1, a voltage induced in SOL B when SOL A is ON (or in SOL A when SOL B is ON) may lead malfunction of the load L.

To prevent this, individual contacts should be provided as shown in Fig.2.



MVS800K/MVD800K Series

4-Port Solenoid Valves

Explosion-proof, Drip-proof

Ceramic slide valve system, Pilot type

Gasket connection type Rc1/4 · 3/8 · 1/2

Return / Hold

This valve can be used as a 3-port valve by closing one of OUT ports (plug).



Specifications

			Return			Hold					
96	Explosion- proof type	Pressure-resistant packing	MVS812	MVS812K - 02 MVS812E - 02 MVS812Y - 02		MVS802K — 03 MVS802E — 03 MVS802Y — 03		2K — 02 2E — 02		2K — 03 2E — 03	
Type	proof type	Conduit tube		3K - 02 3E - 02		3K - 03 3E - 03		MVD813K - 02 MVD813E - 02		MVD803K - 03 MVD803E - 03	
	Drip-pro	of type	MVS81	IK — 02	MVS80	1K — 03	MVD81	1K - 02	MVD80	1K — 03	
Por	t size (R	c)	1/4	3/8	3/8	1/2	1/4	3/8	3/8	1/2	
Effe	ective secti	onal area (CV value)	16mm (0.9)	18mm (1.0)	55mm (3.0)	60mm (3.3)	16mm (0.9)	18mm (1.0)	55mm (3.0)	60mm (3.3)	
Ор	Operating pressure					0.12 ~	0.7MPa				
Pre	Pressure resistance		1.05MPa								
Ор	Operating temperature		- 20 ~ 60°C								
Ор	Operating frequency		1 cycle / s max. / 1 cycle / 6 months min.								
Ор	Operation (response) time		0.1s max.								
	Rated v	oltage	Refer to Model Code								
	Voltage f	fluctuation tolerance	− 15%~ 10% of rated voltage								
bio	Tempera	ature rise	80 deg max. 65 deg max.								
Solenoid	Insulation	on class	Class H								
Š	Insulation resistance		10MΩ min.								
	Rated current		Refer to Rated current data on page A-39								
	Explosio	on-proof standard	Flame-proof enclosure construction d2G4 / Exd II BT4								
Ма	SS					Approx	. 2.0kg				


ullet At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.

[Explosion-proof verification approval No.]

■ d2G4 · Return ■ Exd II BT4 · Return ■ Exd II BT4 · Return (Europe) ■ Exd II BT4 Gb · Return (China) A number changes No. T47926 No. TC16744 TÜV.11.ATEX7945X at every official approval. ■ d2G4 · Hold ■ Exd II BT4 · Hold ■ Exd II BT4 · Return (Korea) ■ Exd II BT4 Gb · Return (Taiwan) A number changes No. T34655 No. TC15045 11 - AV4BO - 0196 at every official approval.

Model Code

When ordering, specify the model as follows:



1 Type of flow path

-	Type of valve	JIS symbol	Designation
position	Return	SOL PR	S
2 pos	Hold (Note) (Magnet-latched system)	SOLB PR SOLA	D

5 Applicable cable size (when housing is 1K* or 2K* or 2E*)

Wire size	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	ϕ 10.5 \sim 11.4	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13

 $\ensuremath{\ensuremath{\%}}$ For size ϕ d , refer to page A-35 from A-38

3 Port size

Port size	Designation
Rc1/4	8A
Rc3/8	10A

4 Port size

Port size	Designation
Rc3/8	10A
Rc1/2	15A

6 Rated voltage

Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 50/60Hz	AC120
AC125V 50/60Hz	AC125 1)
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V

◆ ② and ⑦ is ordering in the pair.


2	2 Type of housing Texplosion-proof verifying nation (Note)				
	Type of housing (External v	Designation	Verifying nation	Designation	
	JIS evaluation proof	Pressure resistant packing system	2K*		
	explosion-proof d2G4	Conduit tube system	3K	Japan	No entry
		Please refer to page C-3 of explosion-proof for hydrogen.		υάραι ι	140 Citily
EX. E	Exd II BT4 (Japan) Exd II BT4 Gb (China)	Pressure resistant packing system	2E*	Japan China	No entry
xplosi	Exd II BT4 (Korea)	Conduit tube system	3E	Korea	Н
ion-proof	Exd II B14 Gb (China) Exd II B14 Gb (China) Conduit tube system II 2G Exd II BT4 Gb (Europe) Exd II BT4 Gb (Taiwan) Pressure resistant packing system		2Y	Europe Taiwan	No entry W
	Drip-proc	f type	1 K *		

^{**} In the case of pressure resistant packing system, drip-proof type please enter the (Note) In the case of an overseas explosion-proof hold type, it is MVD8 type. Consult separately.


In the case of conduit tube system, no need to fill out the 5 applicable cable size.

[Pressure-resistant packing]


MVS812K-02 MVS812E-02 (Return)




MVS812Y-02 (Return)



MVS802K-03 (Return) MVS802E-03




MVS802Y-03 (Return)




[Conduit tube]


[Drip-proof type]

MVS813K-02 (Return)







MVS811K-02 (Return)



MVS803K-03 (Return) MVS803E-03




MVS801K-03 (Return)




(Pressure-resistant packing)

[Conduit tube]


MVD812K-02 (Hold) MVD812E-02




MVD813K-02 MVD813E-02 (Hold)



MVD802K-03 (Hold) MVD802E-03




MVD803K-03 MVD803E-03 (Hold)




[Drip-proof type]

MVD811K-02 (Hold)



MVD801K-03 (Hold)




Precautions in operation circuit design

< Cause of magnet-latched system > (Hold)

If the load L such as relay, lamp or the like is connected in parallel with coil as shown in Fig.1, a voltage induced in SOL B when SOL A is ON (or in SOL A when SOL B is ON) may lead malfunction of the load L.

To prevent this, individual contacts should be provided as shown in Fig.2.



Pilot breathing hole

When the breathing hole operates, it inhales open air.

If this solenoid valve frequently get wet in water, install a street elbow or the like so that the breathing hole faces downward.

453S/453D Series


5-Port Solenoid Valves

Explosion-proof

Spool valve system, Pilot type

Direct piping type Rc1/4 · 3/8 · 1/2

Return / Hold



Specifications

			Ret	urn	Н	old	Ret	turn	Но	old
ā	Explosion- proof type	Pressure-resistant packing	453S202K-E2K 453S202K-E2E 453S202K-E2Y	453S203K-E2K 453S203K-E2E 453S203K-E2Y	453D202K-E2K 453D202K-E2E	453D203K-E2K 453D203K-E2E	453S403C-E2K 453S403C-E2E 453S403C-E2Y	453S404C-E2K 453S404C-E2E 453S404C-E2Y		453D404C-E2K 453D404C-E2E
Туре	proor type	Conduit tube	453S202K-E1K 453S202K-E1E	453S203K-E1K 453S203K-E1E	453D202K-E1K 453D202K-E1E	453D203K-E1K 453D203K-E1E	453S403C-E1K 453S403C-E1E	453S404C-E1K 453S404C-E1E		453D404C-E1K 453D404C-E1E
	Drip-pro	of type	453S202K-E3K	453S203K-E3K	453D202K-E3K	453D203K-E3K	453S403C-E3K	453S404C-E3K	453D403C-E3K	453D404C-E3K
Por	t size (R	c)	1/4	3/8	1/4	3/8	3/8	1/2	3/8	1/2
Effe	ective secti	onal area (CV value)		22mm²	(1.2)			40mm	(2.2)	
Ор	Operating pressure					0.2 ~ 0).7MPa			
Pre	ssure res	istance	1.05MPa							
Ор	erating ter	mperature	- 5 ~ 50°C							
Ор	erating fre	equency	1 cycle / s max. / 1 cycle / 6 months min.							
Ор	eration (re	esponse) time	0.05 s max.							
	Rated vo	oltage	Refer to Model Code							
	Voltage f	luctuation tolerance			- 15	5%~ 10%	of rated vo	Itage		
<u>ā</u>	Tempera	ature rise	80 de	g max.	65 de	g max.	80 de	g max.	65 deg	g max
Solenoid	Insulatio	n class	Class H							
Sc	Insulatio	n resistance	10MΩ min.							
	Rated c	urrent			Refer to F	ated currer	nt data on p	page A-39		
	Explosio	Explosion-proof standard Flame-proof enclosure construction d2G4 / Exd II BT4								
Ма	SS		Approx	. 1.7kg	Approx	. 1.8kg	Approx	. 2.0kg	Approx	. 2.1kg

• At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.

[Explosion-proof verification approval No.]

■ d2G4 · Return

■ Exd II BT4 · Return

■ Exd II BT4 · Return (Europe) ■ Exd II BT4 Gb · Return (China)

No. T47926

No. TC16744

TÜV.11.ATEX7945X

A number changes at every official approval.

■ d2G4 · Hold

■ Exd II BT4 · Hold

■ Exd II BT4 · Return (Korea) ■ Exd II BT4 Gb · Return (Taiwan)

No. T34655


No. TC15045

11 - AV4BO - 0196

A number changes at every official approval.

Model Code

When ordering, specify the model as follows:



1 Type of flow path

	Type of valve	JIS symbol	Designation
position	Return	SOL. R1 P R2	S
2 pos	Hold (Note) (Magnet-latched system)	SOLB R2 PR1 SOLA	D

2 Type of body, port size

Type of body	Port size	Designation
B20	Rc1/4	202K
	Rc3/8	203K
B40	Rc3/8	403C
	Rc1/2	404C

♦ ③ and ⑥ is ordering in the pair.

6	Type of housing	Explosion-pro	of verifying nation		
	Type of housing (External v	Designation	Verifying nation	Designation	
	JIS Pressure resistant packing system		1 2K*		
	explosion-proof d2G4	Conduit tube system 1 K		Japan	No entry
	Explosion-proof for hydrogen d3aG4	Please refer to page C-3 of explosion-proof for hydrogen.			
Į.	Exd II BT4 (Japan)	Pressure resistant packing systen	1 2E*	Japan	No entry
Explos	Exd II BT4 Gb (China) Exd II BT4 (Korea)	Conduit tube system	1E	China Korea	Н
ion-proof	Exd II BT4 Gb (China) Exd II BT4 (Korea) Conduit tube system II 2G Exd II BT4 Gb (Europe) Exd II BT4 Gb (Taiwan) Pressure resistant packing		1 2Y	Europe Taiwan	No entry W
	Drip-proc	f type	3K*		

^{*} In the case of pressure resistant packing system, drip-proof type please enter the 4 applicable cable size. In the case of conduit tube system, no need to fill out the 4 applicable cable size.

4 Applicable cable size (when housing is 2K * or 3K * or 2E *)

Wire size φd *	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	ϕ 10.5 \sim 11.4	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13

[%] For size ϕ d , refer to page A-35 from A-38

0	Rated	voltage
v	naicu	voitage

O Hatoa voltago	
Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 50/60Hz	AC120
AC125V 50/60Hz	AC125 1)
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V


¹⁾ In Ex. Explosion-proof type return valve, AC125 is not applicable.

⁽Note) In the case of an overseas explosion-proof hold type, external form dimensions are different. Consult separately.


When ordering, specify the frequency 50 Hz or 60 Hz.

[Pressure-resistant packing]


453S202 · 203K-E2K 453S202 · 203K-E2E (Return)




453S202 · 203K-E2Y (Return)



453S403 · 404C-E1K 453S403 · 404C-E1E (Return)




453S403 · 404C-E2Y (Return)




[Conduit tube]

453S202 · 203K-E1K (Return)




[Drip-proof type]


453S202 · 203K-E3K (Return)



453S403 · 404C-E2K (Return) 453S403 · 404C-E2E




453S403 · 404C-E3K (Return)




[Pressure-resistant packing]

453D202 · 203K-E2K 453D202 · 203K-E2E (Hold)




453D403 · 404C-E1K 453D403 · 404C-E1E (Hold)




[Conduit tube]

453D202 · 203K-E1K 453D202 · 203K-E1E (Hold)




453D403 · 404C-E2K 453D403 · 404C-E2E (Hold)




[Drip-proof type]

453D202 · 203K-E3K (Hold)



453D403 · 404C-E3K (Hold)




Precautions in operation circuit design

< Cause of magnet-latched system > (Hold)

If the load L such as relay, lamp or the like is connected in parallel with coil as shown in Fig.1, a voltage induced in SOL B when SOL A is ON (or in SOL A when SOL B is ON) may lead malfunction of the load L.

To prevent this, individual contacts should be provided as shown in Fig.2.



MVS2F/MVD2F · MVS2N/MVD2N Series


5-Port Solenoid Valves

Explosion-proof, Drip-proof

Spool valve system, Pilot type

Gasket connection type Rc1/4 \cdot 3/8 \cdot 1/2 \cdot 3/4 \cdot 1

Return / Hold



Specifications

			Return	Hold	Return	Hold
96	Explosion- proof type	Pressure-resistant packing	MVS2F-03-E2K MVS2F-03-E2E MVS2F-03-E2Y	MVD2F-03-E2K MVD2F-03-E2E	MVS2N-08-E2K MVS2N-08-E2E MVS2N-08-E2Y	MVD2N-08-E2K MVD2N-08-E2E
Туре	proor type	Conduit tube	MVS2F-03-E1K MVS2F-03-E1E	MVD2F-03-E1K MVD2F-03-E1E	MVS2N-08-E1K MVS2N-08-E1E	MVD2N-08-E1K MVD2N-08-E1E
	Drip-pro	of type	MVS2F-03-E3K	MVD2F-03-E3K	MVS2N-08-E3K	MVD2N-08-E3K
Por	t size(R	c)	1/4 • 3/	/8·1/2	3/4	• 1
Effe	ective section	onal area (CV value)	40mm (2.2) · 55mm	$(3.0) \cdot 70$ m $^{\circ}$ (3.8)	175mm (9.5) ·	185mm (10.0)
			0.2 ~ (D.7MPa	0.12 ~	0.7MPa
Ор	Operating pressure		In case of separate pilot supply type Pilot operating pressure ≧ Operating pressure			e
Pre	ssure resi	istance	1.05MPa			
Оре	erating ter	mperature	− 5 ~ 60°C		- 20 <i>-</i>	~ 50°C
Оре	erating fre	equency	1 cycle / s max. / 1 cycle / 6 months min.			min.
Оре	eration (re	esponse) time	0.1 s max. 0.3 s max.		max.	
	Rated vo	oltage	Refer to Model Code			
	Voltage f	luctuation tolerance		− 15%~ 10%	of rated voltage	
bio	Tempera	ature rise	80 deg max.	65 deg max.	80 deg max.	65 deg max.
Solenoid	Insulatio	n class	Class H			
Sc	Insulatio	n resistance		10MΩ	Σ min.	
	Rated co	urrent		Refer to Rated currer	nt data on page A-39	
	Explosion-proof standard Flame-proof enclosure construction d2G4 / Exd II B			II BT4		
Ма	SS		Approx	. 3.0kg	Approx	. 5.0kg

• At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.

[Explosion-proof verification approval No.]

■ d2G4 · Return ■ Exd II BT4 · Return No. T47926 No. TC16744 ■ d2G4 · Hold

■ Exd II BT4 · Hold No. T34655 No. TC15045 TÜV.11.ATEX7945X

A number changes at every official approval.


■ Exd II BT4 · Return (Korea) ■ Exd II BT4 Gb · Return (Taiwan)

A number changes 11 - AV4BO - 0196 at every official approval.

■ Exd II BT4 · Return (Europe) ■ Exd II BT4 Gb · Return (China)

Model Code

When ordering, specify the model as follows:



1 Type of flow path Type of valve JIS symbol Designation Return S position Hold (Note) (Magnet-latched D system) R2 P R1

5 Pilot pressure supply system				
Type Designation				
Internal pilot type (Standard)	No entry			
Separate pilot supply type	Р			

◆ ②, ❸ and ⑥ is ordering In three items set.

	23 Type	6 Port size			
	Type of body	Port size	2 Designation	3 Designation	Designation
		Rc1/4			8A
	03	Rc3/8	F	03	10A
		Rc1/2			15A
	08	Rc3/4	N	08	20A
	00	Rc1	IN	08	25A

Applicable cable size (when housing is 2K * or 3K * or 2E *)						
Wire size	Applicable cable size	Designation				
φ 8.5	ϕ 7.5 \sim 8.4	No.8				
φ 9.5	$\phi 8.5 \sim 9.4$	No.9				
φ 10.5	ϕ 9.5 \sim 10.4	No.10				
φ 11.5	ϕ 10.5 \sim 11.4	No.11				
φ 12.5	ϕ 11.5 \sim 12.4	No.12				
φ 13.5	ϕ 12.5 \sim 13.4	No.13				

 $[\]mbox{\%}$ For size ϕ d , refer to page A-35 from A-38

◆ ② and ③ is ordering in the pair.

4 Type of housing			xplosion-proof verifying nation		
	Type of housing (External wire connection system)		Designation	Verifying nation	Designation
	JIS ovalazion proof	Pressure resistant packing system	2K*	Japan No e	No optru
	explosion-proof d2G4	Conduit tube system	1 K		No entry
Exd II Exd II on print II 2G	Exd II BT4 (Japan)	Pressure resistant packing system	2E*	Japan	No entry
	Exd II BT4 Gb (China) Exd II BT4 (Korea)	Conduit tube system	1E	China Korea	H
	II 2G Exd II BT4 Gb (Europe) Exd II BT4 Gb (Taiwan)	Pressure resistant packing system	2Y	Europe Taiwan	No entry W
	Drip-proc	f type	3K*		

^{*} In the case of pressure resistant packing system, drip-proof type please enter the (Note) In the case of an overseas explosion-proof hold type, 7 applicable cable size. external form dimensions are different. Consult separately. In the case of conduit tube system, no need to fill out the papplicable cable size.

8 Rated voltage

Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 50/60Hz	AC120
AC125V 50/60Hz	AC125 1)
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220

Rated voltage	Designation	
DC 24V	DC 24V	
DC 48V	DC 48V	
DC100V	DC100V	
DC110V	DC110V	
DC120V	DC120V	
DC125V	DC125V	


¹⁾ In Ex. Explosion-proof type return valve, AC125 is not applicable.

(Pressure-resistant packing)


MVS2F-03-E2K (Return)

G3/4 Depth 13.5 Conduit tube connection port A-6.7 (Mounting hole) R2 PR R1 PR R2 PR R3 PR R4 PR R5 PR R6 PR R7 PR R7


MVS2F-03-E2Y (Return)



MVS2N-08-E2K (Return)




MVS2N-08-E2Y (Return)




[Conduit tube]

[Drip-proof type]


MVS2F-03-E1K MVS2F-03-E1E (Return)




MVS2F-03-E3K (Return)



MVS2N-08-E1K (Return)




MVS2N-08-E3K (Return)



(Pressure-resistant packing)

[Conduit tube]


MVD2F-03-E2K MVD2F-03-E2E (Hold)




MVD2F-03-E2E-C/H MVD2F-03-E2Y (Hold) :

(The same as A-31 page "MVPCF-03-E2Y")

MVD2F-03-E1K MVD2F-03-E1E (Hold)




MVD2N-08-E2K MVD2N-08-E2E (Hold)



MVD2N-08-E2E-C/H MVD2N-08-E2Y (Hold) :


(The same as A-31 page "MVPCN-08-E2Y")

MVD2N-08-E1K MVD2N-08-E1E (Hold)



[Drip-proof type]

MVD2F-03-E3K (Hold)




Precautions in operation circuit design


< Cause of magnet-latched system > (Hold)

If the load L such as relay, lamp or the like is connected in parallel with coil as shown in Fig.1, a voltage induced in SOL B when SOL A is ON (or in SOL A when SOL B is ON) may lead malfunction of the load L.

To prevent this, individual contacts should be provided as shown in Fig.2.



MVD2N-08-E3K (Hold)



MVPCF/EF/OF • MVPCN/EN/ON Series


5-Port Solenoid Valves

Explosion-proof, Drip-proof

Spool valve system, Pilot type

Gasket connection type Rc1/4 \cdot 3/8 \cdot 1/2 \cdot 3/4 \cdot 1

3 positions (Closed center / Pressure center / Exhaust center)



Specifications

		Closed center	Pressure center	Exhaust center	Closed center	Pressure center	Exhaust center		
Type	Explosion-	Pressure-resistant packing	MVPCF-03-E2K MVPCF-03-E2E MVPCF-03-E2Y	MVPEF-03-E2E	MVP0F-03-E2E		MVPEN-08-E2E		
	proof type	Conduit tube	MVPCF-03-E1K MVPCF-03-E1E		MVP0F-03-E1K MVP0F-03-E1E				
	Drip-pro	of type	MVPCF-03-E3K	MVPEF-03-E3K	MVP0F-03-E3K	MVPCN-08-E3K	MVPEN-08-E3K	MVPON-08-E3K	
Por	t size (R	c)	1	1/4 · 3/8 · 1/2	2		3/4 • 1		
Effe	ective secti	onal area (CV value)	40mm (2.2)	·55mm (3.0) ·	70mm (3.8)	175mm [*]	(9.5) · 185mm	(10.0)	
				$0.2 \sim 0.7 \text{MPa}$ $0.12 \sim 0.7 \text{MPa}$					
Operating pressure		In case of separate pilot supply type Pilot operating pressure ≧ Operating pressure							
Pressure resistance		1.05MPa							
Operating temperature		- 5 ~ 60°C		− 20 ~ 50°C					
Оре	erating fre	equency	1 cycle / s max. /			1 cycle / 6 months min.			
Оре	eration (re	esponse) time	0.1 s max.		0.5 s max.				
	Rated vo	oltage	Refer to Model Code						
	Voltage f	fluctuation tolerance	− 15%~ 10% of rated voltage						
bic	Tempera	ature rise		80 deg max.					
Solenoid	Insulatio	on class			Clas	ass H			
Š	Insulation	on resistance			10MΩ	Ω min.			
	Rated co	urrent		Refer to Rated current			nt data on page A-39		
	Explosio	on-proof standard	Flame-proof enclosure construction d2G4 / Exd II BT4				4		
Ма	SS			Approx. 3.5kg			Approx. 5.5kg		

• At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.

[Explosion-proof verification approval No.]

■ d2G4

■ Exd II BT4 (Europe)

TÜV.11.ATEX7945X

■ Exd II BT4

No. TC16744

No. T47926

■ Exd II BT4 (Korea)

11 - AV4BO - 0196

■ Exd II BT4 Gb (China)


A number changes at every official approval.

■ Exd II BT4 Gb · Return (Taiwan)

A number changes at every official approval.

Model Code

When ordering, specify the model as follows:



1 Type of flow path

Т	ype of valve	JIS symbol	Designation
	Closed center		CF
=	Closed Certier	SOLB R2 P R1 SOL.A	CN
3 position	Pressure	B A	EF
	center	SOLB R2 P R1 SOL.A	EN
	Exhaust		OF
	center	SOLB R2 P R1 SOLA	ON

5 Pilot pressure supply system

Туре	Designation
Internal pilot type (Standard)	No entry
Separate pilot supply type	Р

♦ ②, ③ and ⑥ is ordering In three items set.

2 3 Type	6 Port size			
Type of body	Port size	2 Designation	3 Designation	Designation
	Rc1/4	F		8A
03	Rc3/8		03	10A
	Rc1/2			15A
08	Rc3/4		08	20A
00	Rc1		00	25A

7 Applicable cable size (when housing is 2K* or 3K* or 2E*)

Wire size	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	ϕ 10.5 \sim 11.4	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13

For size ϕ d , refer to page A-35 from A-38

◆ 4 and 9 is ordering in the pair.

	4 Type of housing			Explosion-proof verifying nation		
	Type of housing (External w	vire connection system)	Designation	Verifying nation	Designation	
	JIS	Pressure resistant packing system	2K*	No. on		
	explosion-proof d2G4	Conduit tube system	1 K	Japan	No entry	
EX. Explosion-proof		Pressure resistant packing system	2E*	Japan	No entry	
	Exd II BT4 Gb (China) Exd II BT4 (Korea)	Conduit tube system	1E	China Korea	H	
	II 2G Exd II BT4 Gb (Europe) Pressure resistant packing syst		2Y	Europe Taiwan	No entry W	
	Drip-proof	3K*				

[%] In the case of pressure resistant packing system, drip-proof type please enter the papplicable cable size.

In the case of conduit tube system, no need to fill out the papplicable cable size.

8 Rated voltage


Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 50/60Hz	AC120
AC125V 50/60Hz	AC125 1)
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220


Rated voltage	Designation
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V


(Pressure-resistant packing)

Note) Each of closed center, pressure center and exhaust center is designed to the same outside dimensions.

MVPCF-03-E2K · MVPCF-03-E2E (Closed center) MVPEF-03-E2K · MVPEF-03-E2E (Pressure center) MVPOF-03-E2K · MVPOF-03-E2E (Exhaust center) MVPCF-03-E2Y (Closed center) MVPEF-03-E2Y (Pressure center) MVPOF-03-E2Y (Exhaust center)









MVPCN-08-E2K · MVPCN-08-E2E (Closed center)
MVPEN-08-E2K · MVPEN-08-E2E (Pressure center)
MVPON-08-E2K · MVPON-08-E2E (Exhaust center)

MVPCN-08-E2Y (Closed center) MVPEN-08-E2Y (Pressure center) MVPON-08-E2Y (Exhaust center)

> 2-1/2NPT Conduit tube connection port





[Conduit tube]


MVPOF-03-E1K · MVPOF-03-E1E (Exhaust center)

MVPCF-03-E1K · MVPCF-03-E1E (Closed center) MVPEF-03-E1K · MVPEF-03-E1E (Pressure center)

R2 P R1 (Mounting hole) 2-G1/2 Depth 14 (For China : 1/2NPT) Conduit tube connection port 40 PLT.IN (Rc1/8) Machining subject to separate pilot supply type 119

[Drip-proof type]

MVPCF-03-E3K (Closed center) MVPEF-03-E3K (Pressure center) MVPOF-03-E3K (Exhaust center)




MVPCN-08-E1K · MVPCN-08-E1E (Closed center)
MVPEN-08-E1K · MVPEN-08-E1E (Pressure center)
MVPON-08-E1K · MVPON-08-E1E (Exhaust center)

352
286
218

A B 4-\$\text{\$\ti


MVPCN-08-E3K (Closed center) MVPEN-08-E3K (Pressure center) MVPON-08-E3K (Exhaust center)



Type of proofness and construction 1

■ ME3S · ME33S

Composition and Construction



Applicable Model

<ME3S>

₩VS303K-02

● MVS803K-03

● 453S202C-E1K ● 453S203C-E1K

453S403C-E1K453S404C-E1K

4555404C-ETKMVS2F-03-E1K

MVS2N-08-E1K

● MVPCF-03-E1K

MVPEF-03-E1K

● MVPOF-03-E1K


● MVPCN-08-E1K

● MVPEN-08-E1K

● MVPON-08-E1K

<ME33S>

₩VS313K-02




■ ME9D-K • ME99D-K

Composition and Construction

G½ Terminal section Manual control secton (Push-button) Housing Solenoid section Plunger Pilot valve section Manual control secton (Push-button) Verification approval No. -No. T34655

Applicable Model










- 453D404C-E1KMVD2F-03-E1K
- MVD2N-08-E1K

<ME99D-K>


● MVD313K-02



Type of proofness and construction 2

■ ME32S · ME332S

Composition and Construction



Applicable Model

<ME32S>

₩VS302K-02

● MVS812K-02 ● MVS802K-03

453S202C-E2K 453S203C-E2K

● 453S403C-E2K

453S404C-E2K

MVS2F-03-E2K

MVS2N-08-E2K

■ MVPCF-03-E2K

■ MVPEF-03-E2K

● MVPOF-03-E2K


MVPCN-08-E2K

■ MVPEN-08-E2K

■ MVPON-08-E2K

<ME332S>

₩VS312K-02




■ ME92D-K • ME992D-K

Composition and Construction


$G\frac{3}{4}$ Terminal section pφ Manual control secton (Push-button) Housing Solenoid section Plunger Cable Gland Pilot valve section Manual control secton (Push-button) Verification approval No. -No. T34655

Applicable Model



<ME992D-K>


● MVD312K-02




Type of proofness and construction 3

■ M3S · M33S


Composition and Construction



Applicable Model









■ M9D-K • M99D-K


Composition and Construction



Applicable Model







Rated current data

■ Type of valve: Return type and 3-port valves (Single solenoid) In case of EX. explosion-proof,consult separately.

Rated voltage	Rated curi	rent (mA)	
AC100V 50/60Hz	159	106	
AC110V 50/60Hz	116	82	
AC115V 50/60Hz	129	86	
AC120V 50/60Hz	115	80	
AC125V 50/60Hz	128	82	
AC200V 50/60Hz	78	51	
AC220V 50/60Hz	68	45	
DC 24V	19)2	
DC 48V	95		
DC100V	49		
DC110V	5	50	
DC120V	4	5	
DC125V	4	-6	

[●] The above amperage table, left shows 50Hz AC and right shows 60Hz AC.

■ Type of valve : Hold type (Magnet-latched type)

Rated voltage	Rated current (mA)		
AC100V 50/60Hz	55	50	
AC110V 50/60Hz	60	55	
AC115V 50/60Hz	47	43	
AC120V 50/60Hz	50	45	
AC125V 50/60Hz	52	47	
AC200V 50/60Hz	26	24	
AC220V 50/60Hz	30	26	
DC 24V	210		
DC 48V	105		
DC100V	55		
DC110V	60		
DC120V	40		
DC125V	4	2	

[●] The above amperage table, left shows 50Hz AC and right shows 60Hz AC.




Explosion-proof solenoid valve lineup

vol.2

For pnematic control **5** Port

Compact explosion proof solenoid valve



Mode List (Compact explosion-proof solenoid valves)

Pilot valve

This is a poppet structure few in sliding parts.

A stable operation free from sticking phenomenon for a long time is promised.

A push button (manual operation mechanism) capable of locking is equipped as standard.

Main valve

• In spite of small size, a large flow rate is realized by the main valve. A simple spool valve using an I-type ring in a narrow main body is disposed rationally.


 Connection interface of the main body is available in two types. The actuator can be mounted or mounted in a most suited manner.

(1) NAMUR standard model

This is a five-port solenoid valve for rotary actuator operation adopting the mounting interface specified in NAMUR standard.

(2) Direct piping type

This is a five-port solenoid valve for connecting to the actuator by piping connection. Single installation at a remote position, or coupling type by manifold structure may be realized.





Explosion-proof housing (terminal box)

- In spite of compact shape, the effective layout of the terminal contributes to ease of wiring work.
- In case of explosion-proof construction standard for electric equipment. The cover of the terminal box is opened or closed by using a special tool. It cannot be opened by general tools. (The special cover opening tool is attached to the product.)



- In case of EX. Explosion-proof
 The cover of the terminal box is opened or closed by using a spanner or the like.
- During power supply, do not open or close the cover of the terminal box.



INDEX



Flame-proof enclosure construction

: d2G4 Exd II BT4

Conduit tube system

Drip-proof protection class: IP66

Pressure-resistant packing system

Drip-proof protection class: IP66 Can be used outdoors

4N4 Series	5-Port	Soleno	id val	ves	
NAMUR sta	andard m	nodel			
		• • •		• •	B-3
4N4S102	(B) K-E				
(NAMUR s	tandard n	nodel · R	eturn t	ype)	
• • • • • •		• • •		• •	B-5
4N4D102	(B) K-E	Ξ			
(NAMUR s	tandard n	nodel · H	lold typ	oe)	
					B-6



454Series 5-Port Solenoid valves Direct piping type	
	7
454S (D) Series (Direct piping type · Return & Hold type)	•
B-9	J
454S Series Manifold-type 5-port solenoid valve	
• • • • • • • • • • B-1	l
454S (D) Series Compound-type 5 port solenoid valve	
• • • • • • • • B-13	3
454S (D) Series	
Compound-type 5 port solenoid valve with p-port stop valve	
B-1	5

Т	ec	:hr	٦ic	ca	l c	lat	a										
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B-17

4N4 Series

5-Port Solenoid Valves


Explosion-proof

Spool valve system, Pilot type

NAMUR standard compliant type Rc1/4,1/4NPT

Return / Hold

This is a five-port solenoid valve for changeover of operation of rotary actuator. A by-pass valve is built in the valve main body, and a speed controller for adjusting the exhaust amount is included in the standard equipment.



Specifications

Model	Return	4N4S102K	4N4S10BK					
code	Hold	4N4D102K	4N4D10BK					
Port size		Rc1/4	1/4NPT					
Applicable	fluid	Compressed air						
Operating pressure		0.15 ∼ 0.7MPa						
Ambient	Structural standard	- 5 <i>r</i>	− 5 ~ 60°C					
temperature	Exd II BT4	- 5 <i>c</i>	~ 40°C					
Fluid temp	erature	- 5 to 60° C (between $-$ 5 and 5° C, remove the moistu	re in the working fluid, and be careful not to allow freezing.)					
Operating	frequency	2 cycle / s max. /	1 cycle / 6 months min.					
Lubricated		Unnec	cessary					
Mass		Return: 0.8kg	Hold: 1.4kg					
	Effective sectional area	10mm (only in solenoid valve main body excluding silencer provided with throttle val						
Valve	Operation (response) time	0.05s max.						
section	Allowable air leakage	Below a specified value in JIS B8373 - 1993						
	Pressure resistance	1.2MPa						
	Flame-proof enclosure construction	Flame-proof enclosure construction d2G4 and Exd II BT4						
	Rating	Continuous						
	Voltage fluctuation tolerance	- 15%	%∼ 10%					
	Apparent power (AC)	Energized 7.5 VA (50 Hz), 5.5 VA (60 Hz) or less	Starting 3 times or less of excitation electric power.					
Solenoid section	Power consumption (DC)	4 W or less						
	Insulation class	Class H						
	Temperature rise (resistance method)	60° C or less (at rating)						
	Insulation resistance	10 M Ω or less (I	DC 500 V megger)					
	withstand voltage	AC1500	OV / min.					
Accessory		Mounting bolts, Packing and	d Silencer with throttle valves.					

^{*} The type in brackets [] refers to the piping thread of NPT.


[Explosion-proof verification approval No.]

 ■ d2G4
 ■ Exd II BT4
 ■ Exd II BT4 (Korea)

 No. T49285
 No. TC13728
 13 - AV4BO - 0493

Model Code

When ordering, specify the model as follows:



1 Type of fow path

Type of valve	Designation		
Return	S		
Hold	D		

Port size

Port size	Designation
Rc1/4	102
1/4NPT	10B

3 Explosion-proof standard

Sta	Designation	
Structural standard	d2G4	Е
EX.	Exd II BT4	Р
Explosion-proof	Exd II BT4(for Korea)	Н

Type of housing (External wire connection system)

4 Type of	of housin	g
-----------	-----------	---

Type of housing (Exte	rnal wire connection system)	Designation
Conduit tube	01	
Pressure resistant packing system	ϕ 7.5 \sim 8.4	08
	ϕ 8.5 \sim 9.4	09
	ϕ 9.5 \sim 10.4	10
/applicable \	ϕ 10.5 \sim 11.4	11
cable size /	ϕ 11.5 \sim 12.0	12

5 Rated voltage

Rated voltage	Designation
AC100V 50/60Hz,AC110V 60Hz	1
(AC110V 50Hz,AC120V 60Hz)	2
AC200V 50/60Hz,AC220V 60Hz	3
(AC220V 50Hz,AC240V 60Hz)	4
(DC12V)	8
DC24V	5
(DC48V)	6
DC100V	7
(DC110V)	9
(DC125V)	А

() denotes semi-standard voltage.

6 Type of option (silencer provided with throttle valve)


Type of option	Designation
Without	Υ
With two	В
Port 5 : With one Port 3 : With Plug	Х

7 Type of option (Surge absorber)


Type of option	Designation
Without	0 (Zero)
With surge absorber	Z

8 Solenoid valve working state


Solenoid valve working state	Designation
Normally closed before shipment	No entry
Normally open before shipment	R



4N4S102 (B) K-E (structural standard · NAMUR standard compliant type · Return type)



4N4D102 (B) K-E (structural standard · NAMUR standard compliant type · Hold type)



454 Series

5-Port Solenoid Valves

Explosion-proof

Spool valve system, Pilot type

Direct piping type Rc1/8,1/4,1/8NPT,1/4NPT

Return / Hold

By effective layout of terminal box, ease of piping works is assured in this compact type pressureproof explosion-proof direct piping type solenoid valve.



仕 様



Model	Return	454S101C	454S10AC	454S102C	454S10BC	454S202C	454S20BC	454S203C	454S20CC
code	Hold	454D101C	454D10AC	454D102C	454D10BC	454D202C	454D20BC	454D203C	454D20CC
Port size		Rc1/8	1/8NPT	Rc1/4	1/4NPT	Rc1/4	1/4NPT	Rc3/8	3/8NPT
Applicable	fluid				Compre	ssed air			
Operating pressure					0.15 ~	0.7MPa			
Ambient	Structural standard				− 5 ~	- 60°C			
temperature	Exd II BT4				− 5 ~	√40°C			
Fluid temp	erature	- 5 to 60° C	C (between - 5	and 5°C, rem	ove the moistur	e in the working	g fluid, and be o	careful not to al	low freezing.)
Operating	frequency		2 cy	/cle/s ma	ax. /	1 cycle /	6 months	min.	
Lubricated				Unne	cessary (oi	lless encl	osed)		
Mass		Return: 0.85kg Hold: 1.55kg				Return: 0.9kg Hold: 1.6kg			
	Effective sectional area	10mm 22mm 2							
Valve	Operation (response) time	0.05s max.							
section	Allowable air leakage	Below a specified value in JIS B8373 - 2015							
	Pressure resistance	1.2MPa							
	Flame-proof enclosure construction	Flame-proof enclosure construction d2G4 and Exd II BT4							
	Rating	Continuous							
	Voltage fluctuation tolerance	− 15%~ 10%							
	Apparent power (AC)	Energized 7.5 VA (50 Hz), 5.5 VA (60 Hz) or less Starting 3 times or less of excitation electric power.							ric power.
Solenoid section	Power consumption (DC)	4 W or less							
	Insulation class				Clas	ss H			
	Temperature rise (resistance method)	60° C or less (at rating)							
	Insulation resistance			10 M G	or less (E	C 500 V r	negger)		
	withstand voltage				AC1500	V / min.			

 $[\]ensuremath{\%}$ The type in brackets [$\ensuremath{\ \ \ }$] refers to the piping thread of NPT.

[Explosion-proof verification approval No.]

■ d2G4 ■ Exd II BT4 ■ Exd II BT4 (Korea) No. T49285 No. TC13728 13 - AV4B0 - 0493

Model Code

When ordering, specify the model as follows:



Type of flow path Type of valve JIS symbol Designation Return SOL. RIPR2 Hold SOL.B R2 P R1 SOL.A D

2 Type of body and Port size				
Type of body	Port size	Designation		
	Rc1/8	101		
B10	Rc1/4	102		
ВІО	1/8NPT	10A		
	1/4NPT	10B		
B20	Rc1/4	202		
	Rc3/8	203		
	1/4NPT	20B		
	3/8NPT	20C		

3 Explosion-proof standard			
Sta	Designation		
Structural standard	d2G4	С	
EX.	Exd II BT4	Е	
Explosion-proof	Exd II BT4(for Korea)	Н	

4 Type of housing				
Type of housing (Exte	Type of housing (External wire connection system) Designation			
Conduit tube	system (G1/2)	01		
Pressure	ϕ 7.5 \sim 8.4	08		
resistant	$\phi 8.5 \sim 9.4$	09		
packing system	ϕ 9.5 \sim 10.4	10		
/applicable \	ϕ 10.5 \sim 11.4	11		
cable size /	ϕ 11.5 \sim 12.0	12		


5 Rated voltage			
Rated voltage	Designation		
AC100V 50/60Hz,AC110V 60Hz	1		
(AC110V 50Hz,AC120V 60Hz)	2		
AC200V 50/60Hz,AC220V 60Hz	3		
(AC220V 50Hz,AC240V 60Hz)	4		
(DC12V)	8		
DC24V	5		
(DC48V)	6		
DC100V	7		
(DC110V)	9		
(DC125V)	Α		

() denotes semi-standard voltage.


6 Type of option	
Type of option	Designation
With surge absorber	Z0
External pilot type	P0
External pilot type and with surge absorber	PZ
Not needed	00


454S series (Direct piping type · Return type)

[Pressure-resistant packing]



[Conduit tube]






Model code	L1	L2	L3	S	G	K	MM	NN
454S101C							Rc1/8	Rc1/8
454S102C	163.5	173	214.5	125.5	40	24	Rc1/4	nc1/6
454S10AC	103.5	173	214.5	123.3	40	24	1/8NPT	1/8NPT
454S10BC							1/4NPT	1/OINF1
454S202C							Rc1/4	Rc1/4
454S203C	183.5	193	234.5	135.5	48	28	Rc3/8	nc1/4
454S20BC	100.0	193	234.5	133.3	40	20	1/4NPT	1/4NPT
454S20CC							3/8NPT	174NP1
454D101C							Rc1/8	Rc1/8
454D102C	251	270	353	125.5	40	24	Rc1/4	nC1/6
454D10AC	251	270	333	123.3	40	24	1/8NPT	1/8NPT
454D10BC							1/4NPT	1/ONF1
454D202C							Rc1/4	Rc1/4
454D203C	271	290	373	135.5	48	28	Rc3/8	nC1/4
454D20BC		290	3/3	100.0	40	20	1/4NPT	1/4NPT
454D20CC							3/8NPT	174NP1

(Request separately for Ex. Explosion-proof external dimension drawings.)

454D series (Direct piping type · Hold type)



Model Code

When ordering, specify the model as follows:



Only return, type of short overall length

1 Port size	
Port size	Designation
Rc1/4	202
Rc3/8	203

2 Explosion-proof standard				
Standard Designation				
Structural standard	d2G4	С		
ΕY	Fxd II BT4	F		

Н

Explosion-proof Exd II BT4(for Korea)

5 No. of valve

3 Type of housing			
Type of housing (Exte	Type of housing (External wire connection system)		
Conduit tube	system (G1/2)	01	
Pressure	ϕ 7.5 \sim 8.4	80	
resistant	ϕ 8.5 \sim 9.4	09	
packing system	ϕ 9.5 \sim 10.4	10	
/applicable \	ϕ 10.5 \sim 11.4	11	
cable size	ϕ 11.5 \sim 12.0	12	


4 Rated voltage			
Rated voltage	Designation		
AC100V 50/60Hz,AC110V 60Hz	1		
(AC110V 50Hz,AC120V 60Hz)	2		
AC200V 50/60Hz,AC220V 60Hz	3		
(AC220V 50Hz,AC240V 60Hz)	4		
(DC12V)	8		
DC24V	5		
(DC48V)	6		
DC100V	7		
(DC110V)	9		
(DC125V)	Α		

•	() denotes	semi-standard	voltage	

No. of valve	Designation
2	02
3	03
•	•
:	:
9	09
10	10

Type of option						
Type of option	Designation					
With surge absorber	Z0					
Not needed	00					


454S series · Return type · Manifold-type 5-port solenoid valve



■ JIS simbol

(Request separately for Ex. Explosion-proof external dimension drawings.)

No. of valve (n)	2	3	4	5	6	7	8	9	10
L1	77	104	131	158	185	212	239	266	293
L2	97	124	151	179	205	232	259	286	313
Mass (kg)	2.4	3.5	4.5	5.6	6.6	7.6	8.7	9.7	10.7



B-12

(n=even number)

Model Code

When ordering, specify the model as follows:



Standard type

1 Type of fow path						
Type of valve	JIS symbol	Designation				
Return	SOL. R1 P R2	S				
Hold	SOLB R2 P R1 SOLA	D				
In case	of compound-type	Z				

4 Type of housing					
Type of housing (Exte	Designation				
Conduit tube	Conduit tube system (G1/2)				
Pressure	ϕ 7.5 \sim 8.4	80			
resistant	$\phi 8.5 \sim 9.4$	09			
packing system	ϕ 9.5 \sim 10.4	10			
/applicable \	$\phi 10.5 \sim 11.4$	11			
\cable size /	ϕ 11.5 \sim 12.0	12			

6 No. of valve						
No. of valve	Designation					
2	02					
3	03					
:	:					
9	09					
10	10					

Designation

Z0

00

7 Type of option

Type of option

With surge absorber

Not needed

2 Port size

Port size	Designation
Rc1/4	202
Rc3/8	203

5 Rated voltage
Rated vo

Rated voltage	Designation
AC100V 50/60Hz,AC110V 60Hz	1
(AC110V 50Hz,AC120V 60Hz)	2
AC200V 50/60Hz,AC220V 60Hz	3
(AC220V 50Hz,AC240V 60Hz)	4
(DC12V)	8
DC24V	5
(DC48V)	6
DC100V	7
(DC110V)	9
(DC125V)	Α


) denotes semi-standard voltage.


Port size	Designation
Rc1/4	202
Rc3/8	203


3 Explosion-proof standard	3	Ехр	losion-	proof	standard
----------------------------	---	-----	---------	-------	----------

Sta	Designation	
Structural standard	d2G4	С
EX.	Exd II BT4	E
Explosion-proof	Exd II BT4(for Korea)	Н

454S (D) series · Compound-type 5 port solenoid valve








(Request separately for Ex. Explosion-proof external dimension drawings.)

■ Dimension Table

No. of valve (n)	2	3	4	5	6	7	8	9	10
L1	104	158	212	266	320	374	428	482	536
L2	124	178	232	286	340	394	448	502	556





Model Code

When ordering, specify the model as follows:



Stop valve is provided in P-port supply line.

Type of fow path Type of valve JIS symbol Designation Return SOL. RI PRZ Hold SOLB RZ RI SOLA D In case of mixing ream-type Z

4 Type of housing					
Type of housing (Exte	rnal wire connection system)	Designation			
Conduit tube	01				
Pressure resistant packing system (applicable cable size)	ϕ 7.5 \sim 8.4	80			
	$\phi 8.5 \sim 9.4$	09			
	ϕ 9.5 \sim 10.4	10			
	$\phi 10.5 \sim 11.4$	11			
	ϕ 11.5 \sim 12.0	12			

6 No. of valve						
No. of valve	Designation					
2	02					
3	03					
:	:					
9	09					
10	10					

[•] In case of 00, only item ① is supplied.

2 Port size

Port size	Designation
Rc1/4	202
Rc3/8	203

3 Explosion-proof standard

Sta	Designation	
Structural standard	d2G4	С
EX.	Exd II BT4	E
Explosion-proof	Exd II BT4(for Korea)	Н

5 Rated voltage

Rated voltage	Designation
AC100V 50/60Hz,AC110V 60Hz	1
(AC110V 50Hz,AC120V 60Hz)	2
AC200V 50/60Hz,AC220V 60Hz	3
(AC220V 50Hz,AC240V 60Hz)	4
(DC12V)	8
DC24V	5
(DC48V)	6
DC100V	7
(DC110V)	9
(DC125V)	А


^() denotes semi-standard voltage.


7 Type of option


<u> </u>	
Type of option	Designation
With surge absorber	Z0
With surge absorbe + Pilot Direction "B"	ZB
Not needed	00
With surge absorbe + Pilot Direction "B"	OB

Option of pilot direction is applicable in return type only.

454S (D) series · Compound-type 5 port solenoid valve with P-port stop valve








(Request separately for Ex. Explosion-proof external dimension drawings.)

■ Dimension Table

No. of valve (n)	2	3	4	5	6	7	8	9	10
L1	104	158	212	266	320	374	428	482	536
L2	124	178	232	286	340	394	448	502	556






Technical data



5-port solenoid valve wiring procedure






5-port explosion-proof type solenoid valve wiring procedure

Leading-in method of external conductor to terminal box

Conduit tube system

Using threaded thick steel conduit tube specified in JIS C8305 (Steel conduit tube), bond by five threads or more in complete thread parallel pipe threads (JIS B0202).


For detail of the piping procedure, refer to "Factory explosion-proof electric facility guide for users" (Gas explosion-proof 1994). In case of possibly exposed to corrosive gas or invasion of water or moisture through threaded parts, apply liquid gasket, or other non-curable waterproof or rust preventive material to threaded parts, and then bind the threads.



When connecting thick steel conduit tube or thick steel conduit tube and others, as shown in the drawing, apply a spanner, so that excessive force may not be applied to the terminal box. If excessive force is applied, the explosion-proof performance may be destroyed.

Pressure-resistant packing system

According to the drawing, connect the cables by pressure-proof packing type. Note that the dimension varies with the cable size in the * asterisked parts.



[Assembling procedure]

- Pass the cable in the sequence of gland washer, gland packing, gland washer, cable gland, and gland cover.
- ② Fit the cable clamp to the cable gland, and fix the cable.
- ③ Tighten two hex socket head cap screw uniformly, with care not to tighten unevenly, and connect the cable gland to the terminal box.
- 4 Insert the cable cover into the cable gland, fit the cross-recessed pan head machine screw, and fix the cable cover.

Conduit tube system ▶

(Bore: G1/2)



Pressure-resistant packing system

(Applicable cable size: ϕ 7.5 \sim 12.0)



Electrical connection

Crimp and connect by using furnished crimped terminal (V2-M4 manufactured by Japan Solderless Terminal Co.) and specified YKT-1614 (manufactured by the same). Use conduits in a size of 1.04 to 2.63 mm^{$^{\circ}$}.


Electrical connection


Structural standard:

The cover of the terminal box is built in a locking system to be opened or closed by a special tool. When opening or closing, use the special tool furnished to the product, and fit the end of the tool tightly to the groove of the cover, and turn in the opening or closing direction as shown in the drawing.

Ex. explosion-proof:

The cover of the terminal box can be opened or closed by spanner or the like.





Warning

Before opening or closing the terminal box or when detaching or attaching the electrical terminals, be sure to turn off the power source in advance.


When connecting wires outdoors or in a place where water may intrude, take protective measures properly to prevent rainwater or the like intruding into the terminal box.




Operation changing method of return type solenoid valve (S)


When the return type solenoid valve (S) is mounted on the double-acting type (D) actuator, the standard is "left rotation by solenoid energizing," but reverse operation of "right rotation by solenoid energizing" is possible in the following procedure.


Operation changing method of 5-port explosion-proof type solenoid valve





Rotate the dismounted pilot solenoid valve by 180 degrees, and mount again on the main body (attach two socket head bolts B).






Explosion-proof solenoid valve lineup

vol.3



For pneumatic control 4/5 Port


Explosion-proof solenoid valves for hydrogen



Mode List (Explosion-proof sorenoid valves for hydrogen)

High safety and high reliability guaranteed.

- 1 Usable at explosion class 3a level.
- The housing of the electromagnetic unit is equal in size to the conventional d2G4 type.
- 3 Surge absorber is included in standard equipment as measures against surge.



Explosion-proof solenoid valves for hydrogen of KONAN

Type of Construction for **Explosion-proof**



Flame-proof enclosure construction

: d3aG4

■ Pressure-resistant packing system



MVS812H/MVS802H MVD8-E2H

Specification · · · · · · C-3 Model Code · · · · · · C-4 Dimensions · · · · · · C-5



453SE2H 453DE2H

Specification · · · · · · C-7 Model Code · · · · · · C-8 Dimensions · · · · · · C-9

MVS800K/MVD800K Series


4-Port Solenoid Valves

Explosion-proof

Ceramic slide valve system, Pilot type

Gasket connection type Rc1/4 · 3/8 · 1/2

Return / Hold



Specifications

Type of valve		Return				Hold				
Тур	e Pressure-r	esistant packing	MVS812	2H — 02	MVS802H - 03		MVD8 - 02 - E2H MVD8 - 03 - E2		03 — E2H	
Port size (Rc)			1/4	3/8	3/8	1/2	1/4	3/8	3/8	1/2
Effe	ective sectional a	area (CV value)	16mm (0.9)	18mm (1.0)	55mm (3.0)	60mm (3.3)	16mm (0.9)	18mm (1.0)	55mm (3.0)	60mm (3.3)
Operating pressure			0.12 ~ 0.7MPa							
Pressure resistance						1.05	MPa			
Operating temperature						- 10 ·	~ 60°C			
Operating frequency			1 cycle / s max. / 1 cycle / 6 months min.							
Operation (response) time		0.1s max.								
Rated voltage		е	Refer to Model Code							
	Voltage fluctua	ation tolerance	— 15% ~ 10% of rated voltage							
pid	Temperature rise			80 deg max.						
Solenoid	Insulation cla	nss	Class H							
Sc	Insulation res	sistance	10MΩ min.							
	Rated curren	t	Refer to Rated current data on page C-11							
	Explosion-pro	oof standard	Flame-proof enclosure construction d3aG4							
Ма	Mass		Approx. 2.0kg							


[•] At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.


Explosion-proof verification approval No.

No. T60099

When ordering, specify the model as follows:

(1) Type of valve passage: 2 positions, return.





1 Port size

Port size	Designation
Rc1/4	8A
Rc3/8	10A

Port size

Port size	Designation
Rc3/8	10A
Rc1/2	15A

3 Applicable cable size

Wire size ϕ d *	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	$\phi 10.5 \sim 11.4$	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13

% For size ϕ d , refer to page A-33 from A-36


4 Rated voltage

Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 60Hz	AC120 *
AC125V 50/60Hz	AC125
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V
When ordering enegify either on	nlicable frequency

When ordering, specify either applicable frequency 50 Hz or 60 Hz.

JIS symbol

(2) Type of valve passage: 2 positions, hold.



1 Type of body

Type of body	Port size	Designation
02	Rc1/4, Rc3/8	02
03	Rc3/8, Rc1/2	03

2 Port size

Port size	Type of body	Designation
Rc1/4	02	8A
Rc3/8	02,03	10A
Rc1/2	03	15A

3 Applicable cable size

Wire size φ d ※	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	$\phi 10.5 \sim 11.4$	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13


% For size ϕ d , refer to page A-33 from A-36

4 Rated voltage


Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 60Hz	AC120 *
AC125V 50/60Hz	AC125
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V

^{*} When ordering, specify either applicable frequency 50 Hz or 60 Hz.


MVS812H-02 (Return)




MVS802H-03 (Return)



MVD8-02-E2H (Hold)



MVD8-03-E2H (Hold)



453S/453D Series

5-Port Solenoid Valves

Explosion-proof

Spool valve system, Pilot type

Direct piping type Rc1/4 · 3/8 · 1/2

Return / Hold



Specifications

Тур	e of valve		Return			Hold	
Туре		453S101C-E2H	453\$202K-E2H	453S403C-E2H	453D101C-E2H	453D202K-E2H	453D403C-E2H
		453S102C-E2H	453S203K-E2H	453S404C-E2H	453D102C-E2H	453D203K-E2H	453D404C-E2H
Port size (Rc)		1/8	1/4	3/8	1/8	1/4	3/8
POI	(Size (NC)	1/4	3/8	1/2	1/4	3/8	1/2
Effe	ective sectional area (CV value)	10mm (0.5)	22mm (1.2)	40mm (2.2)	10mm (0.5)	22mm (1.2)	40mm (2.2)
Оре	erating pressure	0.2 ~ 0.7MPa					
Pre	ssure resistance	1.05MPa					
Оре	erating temperature	− 5 ~ 50°C					
Оре	erating frequency	1 cycle / s max. / 1 cycle / 6 months min.					
Оре	eration (response) time	0.05 s max.					
	Rated voltage		Refer to Model Code				
	Voltage fluctuation tolerance		-	- 15%~ 10%	of rated voltag	e	
pio	Temperature rise			61.4 de	eg max.		
Solenoid	Insulation class	Class H 10MΩ min. Refer to Rated current data on page C-11					
S	Insulation resistance						
	Rated current						
	Explosion-proof standard	Flame-proof enclosure construction d3aG4					
Mass Approx.1.7kg Approx.2.0kg Approx.3.0kg		Approx.3.5kg					

[•] At the operating temperature of 5°C or below, use extreme care for protection against frosting by removing the water contained in the fluid for use.

Explosion-proof verification approval No.

No. T60099

When ordering, specify the model as follows:



1 Type of flow path

-	Type of valve	JIS symbol	Designation
position	Return	SOL. R1 P R2	S
2 pos	Hold	SOLB R2 P R1 SOLA	D

2 Type of body, port size

Type of body	Port size	Designation
B10	Rc1/8	101C
	Rc1/4	102C
B20	Rc1/4	202K
	Rc3/8	203K
B40	Rc3/8	403C
	Rc1/2	404C

4 Rated voltage

Rated voltage	Designation
AC100V 50/60Hz	AC100
AC110V 50/60Hz	AC110
AC115V 50/60Hz	AC115
AC120V 60Hz	AC120 *
AC125V 50/60Hz	AC125
AC200V 50/60Hz	AC200
AC220V 50/60Hz	AC220
DC 24V	DC 24V
DC 48V	DC 48V
DC100V	DC100V
DC110V	DC110V
DC120V	DC120V
DC125V	DC125V

 $\ensuremath{\ensuremath{\%}}$ When ordering, specify either applicable frequency 50 Hz or 60 Hz.

3 Applicable cable size

Wire size <i>φ</i> d *	Applicable cable size	Designation
φ 8.5	ϕ 7.5 \sim 8.4	No.8
φ 9.5	$\phi 8.5 \sim 9.4$	No.9
φ 10.5	ϕ 9.5 \sim 10.4	No.10
φ 11.5	ϕ 10.5 \sim 11.4	No.11
φ 12.5	ϕ 11.5 \sim 12.4	No.12
φ 13.5	ϕ 12.5 \sim 13.4	No.13


 $\ensuremath{\text{\%}}$ For size ϕ d , refer to page A-33 from A-36

453S101C-E2H • 453S102C-E2H

453S202K-E2H • 453S203K-E2H


(Return)

453S403C-E2H • 453S404C-E2H



■ Dimension Table

■ Dimension Ta	ble															Ur	nit:mm					
Type code Sign	M (Rc)	N (Rc)	LA	L1	F	G	Н	I	К	S	В	Q	R	Р	Т	U	V					
453S101C-E2H	1/8	1/8	38	67	40				24	40												
453S102C-E2H	1/4	1/0	30	30	36	36	36	30	67	40	26	30	22	24	40	4.2	7.2	3		20	94	122
453S202K-E2H	1/4	1/4	48	95	50	20	30	~~	28	48	4.2	1.2	3	14	20	94	122					
453S203K-E2H	3/8	1/4	40	95	95	95	95	30				28	48				14					
453S403C-E2H	3/8	3/8	63	92	56	36	40	30	36	68	5.3	9.5	4		28	96	124					
453S404C-E2H	1/2	1/2	0.5	92	96	56	56	56	30	40	30	30	00	5.5	9.5	4		20	90	124		



Rated current data

Rated voltage	Rated current (mA)				
AC100V 50/60Hz	192	127			
AC110V 50/60Hz	183	159			
AC115V 50/60Hz	146	124			
AC120V 60Hz		146			
AC200V 50/60Hz	96	62			
AC220V 50/60Hz	91	80			
DC 24V	30	3			
DC 48V	15	4			
DC100V	7	5			
DC110V	55				
DC120V	59				
DC125V	6	0			

[●] The above amperage table, left shows 50Hz AC and right shows 60Hz AC.


Explosion-proof solenoid valve lineup

vol.4



For pnematic control **5** Port

Intrinsic safety solenoid valves



Mode List (Intrinsic safety solenoid valves)

Exia II BT5


- This is the intrinsic safety construction usable at the same explosion class, and same degree of ignition as the Exd II BT5 (Flame-proof enclosure construction).
- Applicable to all explosive gases and dangerous places, except for hydrogen, acetylene, and carbon disulfide.



Sarrie

Intrinsic safety construction: Exia II BX

Intrinsic safety construction: Exia II C




Substantial cost saving in wiring works

- Not requiring expensive wiring devices or complicated works conventionally needed for Explosion-proof enclosure construction.
 Highly reliable explosion-proof performance is realized at low wiring work cost as in the ordinary control line.

Power consumption: 0.4 W

- The solenoid valve installed in a dangerous place consumes very low electric power of only 0.4 W, while satisfying the intrinsic safety explosion-proof level.
- This is a 5-port pneumatic solenoid valve of high reliability, based on our New MAGSTAR series.
 An excellent space factor is obtained by using the manifold type solenoid valvs.




Cautions for use





In both solenoid valve and explosion-proof barrier, strictly observe the conditions of use specified in the specification column of each manufacturer.



Solenoid valve wiring method









When connecting wires to the solenoid valve, be careful not to mistake the polarity.



Push-button (manual operation mechanism)

- By pushing the push-button (red), the solenoid valve is actuated, and when released, it is returned to the original state.
- When locking the push-button, use the blade of a screwdriver or the like, and turn the push-button to the right, and it will be locked. When turned to the left, it will be unlocked.
- When the push-button is locked, after operation, turn to the left to unlock. (If turned while pushing the push-button, the same action takes place, and there is no problem.)







In principle, use the solenoid valve without lubrication. For working fluid, use fresh air, and do not mix with deteriorated compressor oil or the like.



At the inlet side (P-port) upstream of the solenoid valve, install an air filter (filtration degree: 5μ or less), and remove dust and drain.




If leaving it behind without use for 1 year or longer, check it before use.

Installation of Intrinsic safety solenoid valves


1. Hazardous area non-hazardous area


To install the Intrinsic safety solenoid valves, as shown in the drawing below, place the switch and the explosion-proof barrier in non-hazardous area, and place only the solenoid valve in hazardous area.



$^-$ Caution -

In the above intrinsic safety circuit, install the switch or the contact to be placed in non-hazardous area always at the (+) side of the power source. If installed at the (-) side, depending on the circumstances, the solenoid valve may malfunction. In particular, when controlled by the sequencer or the like, it cannot be used if the common side of the sequencer output circuit is connected to the minus side of the power source.





2. Combination of explosion-proof solenoid valves and explosion-proof barrier

The explosion-proof barrier should be always used in the intrinsic safety construction. In combination with the solenoid valve, use one explosion-proof barrier alone for one solenoid valve.

Caution -

In case of the hold type solenoid valve (double solenoid), it must be noted that two explosion-proof barriers are needed.

SAF3-5 (Exia II BT5)

Explosion-proof barrier (safety barrier)

Intrinsic safety construction


The intrinsic safety explosion-proof barrier is a onechannel explosion-proof device of shunt diode type for direct-current use, for passing electrical signals in both directions without short-circuiting, while limiting the energy transmission to the level not to ignite the explosive atmosphere.



- 1. Applicable to class 0 hazardous area.
- 2. Only by connecting in series to the transmission circuit, the line and the device in the hazardous area can be protected from accidents in non-hazardous area.
- 3. The conventional wiring system can be used in the hazardous area.
- 4. The intrinsic safety of control operation signal can be realized easily and at low cost.
- 5. SAF3-5 safety barrier is provided with a protective circuit at the input side, and if connected in wrong polarity by mistake, the circuit will not be broken.
- 6. SAF3-5 safety barrier is designed in wiring and connection system by crimped terminal.
- 7. Explosion-proof standard: If selecting an solenoid valve of Exia II BT5, use the explosion-proof barrier in combination with the SAF3-5, SAF100-5, or the barrier satisfying the condition specified in page D-6 [When selecting other explosion-proof barriers].

Specifications

Type code	SAF3-5				
Explosion-proof structure	Intrinsic safety construction (Exia II B)				
Rated voltage	DC24V ± 5%				
Max. operating voltage	_				
Max. allowable voltage	_				
Safety holding rating	AC/DC 250V				
Fuse rating	50mA				
ambient temperature	- 20 ~ 60°C				
Basic circuit diagram	[Hazardous area] [Non-hazardous area] Solenoid valve				
Option	DIN rail for mountingEarth busbarOthers				
Conditions of use	I) Install at non-hazardous area side. 2) Ground independently, and use in class A grounding. 3) The parts and the wiring cannot be changed. 4) Use in combination with specified solenoid valve. 5) Allowable in external wiring, inductance: 10 mH · capacitance: 0.5 µF.				
Remarks	_				



Caution

Safety holding rating

- Devices (power switch and others) connected to the explosion-proof barrier in the non-hazardous area should be free from parts composing voltage wires exceeding 250 V (RMS) or 250 V (DC) in the ground potential in usual time or in the event of accident, or parts supplied from such voltage wires.
- If power is supplied from the main bus, isolation from the main bus is required by means of double winding transformer, and the primary winding should be protected by a fuse having a conforming interrupting capacity (rating).

2. Inductance and capacitance of external wiring

The wiring length (between barrier and solenoid valve) is limited by the inductance and capacitance of the wiring. General parameters are as follows.

	SAF3-5
In case of capacitance: 100 pF/m Maximum wiring length to stay below the capacitance allowable in external wiring	5000m
In case of inductance : 25 μ H Ω / DC resistance : 40 Ω /km Maximum wiring length to stay below the inductance allowable in external wiring in both directions	5000m

3. General handling of explosion-proof barrier

Refer to the general handling cautions of Intrinsic safety solenoid valves and explosion-proof barrier mentioned in page D-4.

When selecting other explosion-proof barriers

KONAN Intrinsic safety solenoid valves [454], [414], and [416] series are approved by the device verification of intrinsic safety explosion-proof of solenoid valve own body. They can be used also in combination with the barrier satisfying the following conditions. (Also possible to combine with the insulation barrier not requiring class A grounding.)

* However, limited only to barriers approved by device verification as a single body, and satisfying the following conditions.

< Safety holding rating >

Intrinsic safety circuit max. voltage: 29.4 V or less Intrinsic safety circuit max. current: 93.8 mA or less Intrinsic safety circuit max. power: 0.689 W or less

< Performance division and group >

Performance division: ia

Group: IIB or IIC

< Relation between intrinsic safety circuit allowable inductance (Lo) and capacitance (Co), and intrinsic safety circuit external wiring inductance (Lw) and capacitance Cw) > Intrinsic safety circuit allowable inductance : Lo ≥ Li + Lw (mH)

Intrinsic safety circuit allowable capacitance : Co \geq Ci + Cw (μ F)

SAF100-5 (Exia II C)

Explosion-proof Insulation barrier (safety barrier)

Intrinsic safety construction

The intrinsic safety explosion-proof barrier is a onechannel explosion-proof device of Zener diode type for direct-current use, for passing electrical signals in both directions without short-circuiting, while limiting the energy transmission to a degree not igniting the explosive atmosphere.




- 1. Applicable to class 0 dangerous zone.
- 2. No grounding is required between the input and the output are insulated.
- 3. Only by connecting in series to the transmission circuit, the line and the device in the hazardous area can protected from accidents in non-hazardous area.
- 4. The conventional wiring system can be used in the hazardous area.
- 5. The intrinsic safety of control operation signal can be realized easily and at low cost.
- 6. Wiring and connection system realized by crimped terminal.
- 7. The input side is provided with a protective circuit, and is not broken if connected in wrong polarity by mistake.
- 8. The presence or absence of input and output can be confirmed by lighting of LED.

Specifications

Type code	SAF100-5					
Explosion-proof structure	Intrinsic safety construction (Exia II C)					
Operating voltage	DC24V ± 10%					
Intrinsic safety circuit max.	DC29.4V					
Intrinsic safety circuit max. current	93.8mA					
Intrinsic safety circuit max. power:	0.689W					
ambient temperature	− 20 ~ 50°C					
Basic circuit diagram	■ Grounding not required. Solenoid valve and other intrinsic safety device SAF100-5 2					
Conditions of use	DIN rail for mountingOthers					
Remarks	 Install at non-hazardous area side. The parts and the wiring cannot be changed. Use in combination with specified solenoid valve. μF Allowable in external wiring, inductance: 2 mH, capacitance: 0.05 μF. 					

LED(橙) LED(緑) MONAN KONAN OUTPUT INPUT SAF100-5 型式検定合格銘板 Ex 絶縁バリヤ SAF100-5 本質安全防爆構造 [Exia]**重**C 110 70 28

Output characteristic graph



Caution -

Safety holding rating

- Devices (power switch and others) connected to the explosion-proof barrier in the non-hazardous area should be free from parts composing voltage wires exceeding 250 V (RMS) or 250 V (DC) in the ground potential in usual time or in the event of accident, or parts supplied from such voltage wires.
- If power is supplied from the main bus, isolation from the main bus is required by means of double winding transformer, and the primary winding should be protected by a fuse having a conforming interrupting capacity (rating).

2. Inductance and capacitance of external wiring

- The wiring length (between barrier and solenoid valve) is limited by the inductance and capacitance of the wiring. General parameters are as follows.
- Supposing the capacitance: 100 pF/m, the maximum length is 500 m.
- Supposing the inductance: 25 $\mu H~\Omega$, the resistance value is 80 Ω approximately. When the DC resistance value is 40 Ω /km, it is 80 Ω or less in both directions. The maximum length is 1000 m.

3. General handling of explosion-proof barrier

Refer to the general handling cautions of Intrinsic safety solenoid valves and explosion-proof barrier mentioned in page D-4.

[When selecting other explosion-proof barriers] -

KONAN Intrinsic safety solenoid valves [454], [414], and [416] series are approved by the device verification of intrinsic safety explosion-proof of solenoid valve own body. They can be used also in combination with the barrier satisfying the following conditions. (Also possible to combine with the insulation barrier not requiring class A grounding.)

* However, limited only to barriers approved by device verification as a single body, and satisfying the following conditions.

< Safety holding rating >

Intrinsic safety circuit max. voltage: 29.4 V or less Intrinsic safety circuit max. current: 93.8 mA or less Intrinsic safety circuit max. power: 0.689 W or less

< Performance division and group >

Performance division: ia

Group: IIB or IIC

< Relation between intrinsic safety circuit allowable inductance (Lo) and capacitance (Co), and intrinsic safety circuit external wiring inductance (Lw) and capacitance Cw) > Intrinsic safety circuit allowable inductance : Lo ≥ Li + Lw (mH)

Intrinsic safety circuit allowable capacitance : Co \geq Ci + Cw (μ F)

454S/454D Series (Exia II BT5)


5-Port Solenoid Valves

Intrinsic safety construction

Spool valve system, Pilot type

Direct piping type Rc1/4 · 3/8 · 1/2

Return / Hold




Specifications

		Return Hold			old					
Туре		454S20 [K-YI-M	454S40	□ M - YI	454D20 🗆 K - YI - M 454D40 🗆 M - Y				
Port size (F	Rc)	1/4	3,	/8	1/2	1/4 3/8 1/2				
Effective sect	ional area (mm²)	2	2	4	0	2	2	4	.0	
Operating p	ressure				0.2 ~ (0.7MPa				
Pressure res	sistance				1.05	MPa				
Operating to	emperature				− 5 ~	- 50°C				
Operating fr	equency				1 cycle	s max.				
Operation (response) time	0.11 :	s max.	0.11 s	max.	0.11 s	s max.	0.11 s	s max.	
	Rated voltage		DC	12V · 34m	4 — (Intrin	nsic safety	Circuit Rati	ng)		
	Temperature rise	12 deg max.								
Solenoid	Insulation class	Class B								
Soleriola	Insulation resistance	10MΩ min. (DC500V)								
	Power consumption	0.4W								
	Explosion-proof standard		Int	rinsic safet	/ construct	ion: i2G4	/ Exia Ⅱ B	T5		
Mass (kg)		Appro	x. 0.4	Appro	x.0.7	Appro	ox.0.5	Appro	ox.0.9	
Explosion-papproval No	roof verification	When combin	ed with explosi	on-proof barrier	satisfying the	conditions mer	ntioned in page	D-6,D-8: No. 1	ГС14813	
Use condition	ons	Use the bother (2) The p	the explosion arrier satisf explosion- parts and the mbination v	tion with spon-proof bar fying the co proof barrie ne wiring ca with one ele	rier in com ndition spers]. nnot be ch	abination wi ecified in pa	age D-6,D-8	3 (When se	electing	

 $^{\% \ \}text{If the ambient temperature is less than} \ 5^\circ\!\text{C} \ , \\ \text{remove the moisture in the working fluid, and be careful not to allow freezing.}$


^{**} Consult our company if exchanging the solenoid valve (F/G type) used in combination with the specified barrier SAF1-5/SAF2-5 of former type.

When ordering, specify the model as follows:




Type of Type of body, port size, fow path Explosion-proof code

2 Type of body, port size, Explosion-proof code							
Type of body	Port size	Designation					
B20	Rc1/4	202K-YI-M					
D2U	Rc3/8	203K-YI-M					
B40	Rc3/8	403M-YI					
B40	Rc1/2	404M-YI					



Wire connection diagram



414S/416S Series (Exia II BT5)


5-Port Solenoid Valves

Intrinsic safety construction

Pilot type

Gasket connection type Rc1/4 \cdot 3/8 \cdot 1/2

Return



Specifications

[5-port, sub-plate type]

		Return						1			
Туре		41483	0 🗆 M	41486	60 🗆 M	416S30 🗆 M 416S60 🗆			60 🗌 M		
Port size (F	Rc)	1/4	3.	/8	1/2	1/4 3/8 1/2			1/2		
Effective sect	tional area (mm²)	25	30	51	60	24	28	51	60		
Operating p	ressure		0.2 ~ (0.7MPa			0.12 ~	0.7MPa			
Pressure res	sistance				1.05	MPa					
Operating to	emperature		− 5 ~	~ 50°C			- 10 ⁻	~ 60°C			
Operating fr	equency				1 cycle /	s max.					
Operation (response) time	0.14 s	s max.	0.16	s max.	0.14 s	s max.	0.16	s max.		
	Rated voltage		DC	12V · 34m	A — (Intrin	sic safety (Circuit Rati	ng)			
	Temperature rise		12 deg max.								
Solenoid	Insulation class	Class B									
Soleriola	Insulation resistance	$10M\Omega$ min. (DC500V)									
	Power consumption	0.4W									
	Explosion-proof standard			Intrinsic s	afety const	ruction: Ex	kia II BT5				
Mass (kg)		Approx.1.3 Approx.2.2 Approx.1.3			x.1.3	Approx.2.2					
Explosion-pi approval No	roof verification).	When combined with explosion-proof barriers satisfying the conditions mentioned in page D-6,D-8: No. TC14814 When combined with safety barrier, MTL728+: No. T42154					TC14814				
Use condition	ons	Use the bother (2) The p	the explosion arrier satis explosion- parts and the mbination w	on-proof ba fying the co proof barrie ne wiring ca	ecified safe rrier in com andition spe ers]. annot be ch ectromagne	bination wi cified in pa anged.	age D-6,D-8	3 (When se	electing		

 $[\]label{eq:continuous} \begin{tabular}{ll} \& If the ambient temperature is less than 5°C , remove the moisture in the working fluid, and be careful not to allow freezing. \end{tabular}$

^{**} Consult our company if exchanging the solenoid valve (F/G type) used in combination with the specified barrier SAF1-5/SAF2-5 of former type.

When ordering, specify the model as follows:




Type of main valve port size


1 Type of main valve						
Type of main valve	Designation					
Spool valve system	4					
Ceramic slide valve system	6					

2 Type of body, port size								
Type of body	Port size	Designation						
B30	Rc1/4	302						
ВЗО	Rc3/8	303						
B60	Rc3/8	603						
	Rc1/2	604						

Outside Dimensions



Wire connection diagram



414S/416S Series (Exia II BT5)

5-Port Solenoid Valves

Intrinsic safety construction

- Pilot type

Gasket connection type Rc1/4 \cdot 3/8 \cdot 1/2

Return



Specifications

[5-port, sub-plate type]

		Return							
Туре		414S30 M 414S60 C		60 🗆 M	416S30 □ M		41686	60 🗆 M	
Port size (F	Rc)	1/4	3.	/8	1/2	1/4	1/4 3/8 1/2		
Effective sect	tional area (mm²)	25	30	51	60	24	28	51	60
Operating p	ressure		0.2 ~ (0.7MPa			0.12 ~	0.7MPa	
Pressure res	sistance				1.05	MPa			
Operating to	emperature		− 5 ~	~ 50°C			- 10 <i>-</i>	~ 60℃	
Operating fr	equency				1 cycle /	s max.			
Operation (response) time	0.14 :	s max.	0.16	s max.	0.14 s	s max.	0.16	s max.
	Rated voltage		DC	12V · 34m	A — (Intrin	sic safety (Circuit Rati	ng)	
	Temperature rise				12 de	g max.			
Solenoid	Insulation class	Class B							
Soleriola	Insulation resistance	$10M\Omega$ min. (DC500V)							
	Power consumption	0.4W							
	Explosion-proof standard			Intrinsic sa	afety consti	ruction: iEx	xia II BT5		
Mass (kg)		Appro	ox.1.3	Appro	x.2.2	Appro	Approx.1.3 Approx		
Explosion-papproval No	roof verification).	When combined with explosion-proof barriers satisfying the conditions mentioned in page D-6,D-8: No. TC14814					TC14814		
Use condition	ons	Use the bother (2) The p	the explosion arrier satis explosion- parts and the mbination w	tion with sp on-proof ba fying the co proof barrie ne wiring ca with one ele	rrier in com andition spe ers]. annot be ch	bination wi ecified in pa anged.	age D-6,D-8	3 (When se	electing

[#] If the ambient temperature is less than 5°C , remove the moisture in the working fluid, and be careful not to allow freezing.

When ordering, specify the model as follows:




Type of Type of body, main valve port size


1 Type of main valve	
Type of main valve	Designation
Spool valve system	4
Ceramic slide valve system	6

2 Type of bod	2 Type of body, port size											
Type of body	Port size	Designation										
B30	Rc1/4	302										
ВЗО	Rc3/8	303										
B60	Rc3/8	603										
800	Rc1/2	604										

Outside Dimensions




Wire connection diagram



YA terminal block

- KONAN's original wiring system resistant to vibration. Optimum wiring method for wiring by using external wiring, or wiring requiring a long lead wire.
- The standard equipment includes a rigid terminal cover made of aluminum die-casting.



454S/454D Series

5-Port Solenoid Valves


Intrinsic safety construction

Manifold Type

Exia II BT5

Spool valve system, Pilot type

Return / Hold




Individual exhaust: C

This is the quick mounting manifold type solenoid valve in which R1 and R2 (exhaust) ports can be individually taken out together with the solenoid valve. This type is optimum in case when to control connected load (air cylinder)'s speed with the exhaust valve (exhaust throttling valve).

Applicable types of the main body

B20,B40



Concentrated exhaust: D


This is the quick mounting manifold type solenoid valve in which R1 and R2 (exhaust) ports of the mounted solenoid valves are made common.

Making exhaust ports common and collective


Making exhaust ports common and collective facilitates line control.

Applicable types of the main body

B20,B40



When ordering, specify the model as follows:



1 Type of flow path

Type of valve	JIS symbol	Designation
Return	SOL. RI P R2	S
Hold	SOLB R2 PR1 SOLA	D

We can manufacture mixed manifolds of both S: return and D: hold type. Enquire when ordering.

2 Type of body, port size, Explosion-proof code

Type of body	Port size	Designation				
B20	Rc1/4	202K-YI-M				
B20	Rc3/8	203K-YI-M				
D40	Rc3/8	403M-YI				
B40	Rc1/2	404M - YI				

3 Type of manifold

Ty	pe of manifold	Designation
Individual exhaust	P R2 R1	C
Concentrated exhaust	R2 P R1	D


4 No. of valve

No. of valve	Designation
2	02
3	03
::	:
19	19
20	20
Spare solenoid valve Specify "00" when ordering the double acting solenoid valve main body <without base="" coupling=""> of spare parts or the like.</without>	00


Explosion-proof verification approval No.	When combined with explosion-proof barriers satisfying the conditions mentioned in page D-6, D-8: No. TC14813
Use conditions	 Use in combination with specified safety barrier. Use the explosion-proof barrier in combination with the SAF3-5,SAF100-5 or the barrier satisfying the condition specified in page D-6,D-8 [When selecting other explosion-proof barriers]. The parts and the wiring cannot be changed. In combination with one electromagnetic valve, use one explosion-proof barrier alone.

■ Individual exhausting

454 \square 20 \square K - YI - M - C \square 454 \square 40 \square M - YI - C \square



L2




Dimension Table

Unit: mm Type code Μ Ν PM LA LU ECM ΕP EW GM GL JM Κ S W 454S202K-YI-M-C □ Rc1/4 94.5 Rc3/8 454S203K-YI-M-C M6 Rc1/4 Rc3/8 40 146 20 40 27 30 28 48 20 Depth 8 454D202K-YI-M-C □ Rc1/4 105 454D203K-YI-M-C □ Rc3/8 454S403M-YI-C □ Rc3/8 Rc3/8 110 454S404M-YI-C □ Rc1/2 Rc1/2 M8 Rc1/2 147 50 37 40 36 68 30 55 50 Depth 11 454D403M-YI-C 🗌 Rc3/8 Rc3/8 135 Rc1/2 454D404M-YI-C Rc1/2


Type code No. of	valve	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
454 □ 202K/203K-YI-M-C □	L1	87	114	141	168	195	222	249	276	303	330	357	384	411	438	465	492	519	546	573
454 \(\) 202K/203K-YI-WI-C \(\)	L2	107	134	161	188	215	242	269	296	333	350	377	404	431	458	485	512	539	566	593
454 □ 403M/404M-YI-C □	L1	117	154	191	228	265	302	339	376	413	450	487	524	561	598	638	672	709	746	783
434 <u>403</u> (VI) 404(VI-11-C <u></u>	L2	137	174	201	248	285	322	359	396	433	470	507	544	581	618	655	692	729	766	803


■ JIS symbol



■ Concentrated exhaust

454 \square 20 \square K - YI - M - D \square 454 □ 40 □ M − YI − D □






■ Dimension Table

Unit: mm

Type code	М	NM	PM	LA	LU	ECM	EM	EP	EW	GM	GL	JM	K	LL2	SN	W
454S202K-YI-M-D □	Rc1/4			94.5		136				27	25		28	219		
454S203K-YI-M-D □	Rc3/8	Rc1/4	Rc3/8	94.5	40		18	13	31			7			28	80
454D202K-YI-M-D □	Rc1/4	nC1/4	HC3/6	105								9			38	00
454D203K-YI-M-D □	Rc3/8															
454S403M-YI-D □	Rc3/8			110												
454S404M-YI-D □	Rc1/2	Rc1/2	Do1 /0	110	55	137				37						110
454D403M-YI-D □	Rc3/8	nc1/2		135	55	137	23	10	40	37	30	9	30	234	30	110
454D404M-YI-D □	Rc1/2			133												


Type code	valve	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
454 □ 202K/203K-YI-M-D □	L1	77	104	131	158	185	212	239	266	293	320	347	374	401	428	455	482	509	536	563
404 \(\text{202R/200R-11-WI-D} \(L2	97	124	151	178	205	232	259	286	313	340	367	394	421	448	475	502	529	556	583
454 ☐ 403M/404M-YI-D ☐	L1	97	134	171	208	245	282	319	356	393	430	467	504	541	578	615	652	689	726	763
454 <u>403</u> 403 404 404 404 404 404 404 404	L2	117	154	191	228	265	302	339	376	413	450	487	524	561	598	635	672	709	746	783

■ JIS symbol



What's d2G4 / Exd II BT4?

For explosion-proof construction of electric equipment, the construction standards and technical standards, specifying 6 explosion-proof constructions each, are established according to the application, type of explosive gas used, or location of the equipment. Such specifications are expressed in codes such as "d2G4" and "Exd II BT4." Each of the codes has the following meanings.



Exd II BT4 Flame-proof enclosure construction d **Technical** proof standards 0 Oil-immersion construction conforming to the international Pressurized apparatus construction 6 р standards explos (Ex explosion-proof е Increasedn safty construction Type of explo construction type) ia Intrinsic safty construction ib Special type of protection construction S n Type n construction ΠA Propane etc. type IΙΒ Ethylene etc. steam IIC ΑII ŏ Gas 450°C T1 Temperature class (surface max.temperature) T2 300℃ T3 200℃

Explosive gas classification according to explosive class and ignition degree (construction standard)

		nition gree	G	1	G2	G3	G4	G5
	1		Acrylonitrile Acetone Ammonia Carbon monoxide Ethane Acetic acid	Ethyl acetate Toluene Propane Benzene Methanol Methane	Ethanol Isopentyl acetate 1-Butanol Butane	Gasoline Dimethyl ether Hexane	Acetaldehyde Diethyl ether	
ı	2				Ethylene Ethylene oxide			
	3 a b c n		Water gas		Acetylene ter gas /Hydroge	n/Acetylene/Cart	oon disulfide	Carbon disulfide
1	Vote) □		gray mark	ed are ap	olicable range	of d2G4.		

Explosive gas classification according to gas or steam type and temperature class (Ex explosion-proof type)

135°C

100°C 85°C

T4

T5

T6

Temperature class Gas or steam type	T1	T2	Т3	T4	T5	Т6
ΠA	Acetone Benzene Ammonia Methane Ethane Acetic acid Ethyl acetate Toluene	1-Butanol Butane Propane Methanol	Hexane	Acetaldehyde Trimethylamine		
IB	Acrylonitrile Carbon monoxide	Ethanol Ethylene Ethylene oxide	Dimethyl ether	Diethyl ether		
IIC	Water gas Hydrogen	Acetylene				Carbon disulfide

Distributing Agent

Note) gray marked are applicable range of Exd II BT4.

KONAN®

KONAN ELECTRIC CO.,LTD.

Tokyo Branch

Shiba-Sanesu-Wakamatsu Bldg.7-8, Shiba 4-chome, Minatoku, Tokyo 108-0014, Japan Phone:+81-3-3454-1711 Fax:+81-3-3454-8699

Osaka Branch

Hankyu Terminal Bldg.1-4, Shibata 1-chome, Kitaku, Osaka 530-0012, Japan Phone:+81-6-6373-6701 Fax:+81-6-6373-6740

Seibu Branch

Momiji Hiroshima Hikarimachi Bldg.12-20, Hikarimachi, 1-chome, Higashiku, Hiroshima,

732-0052, Japan Phone: +81-82-568-0071 Fax: +81-82-568-0072

International Operation Division 4-97, Uedahigashimachi, Nishinomiya, Hyogo, 663-8133, Japan Phone:+81-798-48-5931 Fax:+81-798-40-6659

URL=https://www.konan-em.com/



Tohoku Office Phone:+81-22-215-1195 Hokkaido Office Phone:+81-11-792-7451 Nagoya Office Phone:+81-52-581-6541 Kanazawa Office Phone:+81-76-233-1411 Hiroshima Office Phone:+81-82-568-0071

Takamatsu Office Phone:+81-87-835-0411 Kitakyushu Office Phone:+81-93-541-0281

2018.05